EN

FR

ES

MP3/WMA/AAC CD RECEIVER WITH BLUETOOTH®

CDE-126BT

MP3 CD RECEIVER WITH BLUETOOTH®

CDE-125BT

Made for iPod iPhone

Bluetooth®

Parrot move wireless

Front Connectors

Cable for iPod Included

(CDE-126BT only)

- OWNER'S MANUAL
  Please read before using this equipment.
- MODE D'EMPLOI
  Veuillez lire avant d'utiliser cet appareil.
- MANUAL DE OPERACIÓN
  Léalo antes de utilizar este equipo.

ALPINE ELECTRONICS MARKETING, INC.
1-1-8 Nishi Gotanda,
Shinagawa-ku,
Tokyo 141-0031, Japan
Phone 03-5496-8231

ALPINE ELECTRONICS OF AMERICA, INC.
19145 Gramercy Place, Torrance,
California 90501, U.S.A.
Phone 1-800-ALPINE-1 (1-800-257-4631)

ALPINE ELECTRONICS OF CANADA, INC.
777 Supertest Road, Toronto,
Ontario M3J 2M9, Canada
Phone 1-800-ALPINE-1 (1-800-257-4631)

ALPINE ELECTRONICS OF AUSTRALIA PTY. LTD.
161-165 Princes Highway, Hallam
Victoria 3803, Australia
Phone 03-8787-1200

ALPINE ELECTRONICS GmbH
Wilhelm-Wagenfeld-Str. 1-3, 80807 München,
Germany
Phone 089-32 42 640

ALPINE ELECTRONICS OF U.K. LTD.
Alpine House
Fletchamstead Highway, Coventry CV4 9TW, U.K.
Phone 0870-33 33 763

ALPINE ELECTRONICS FRANCE S.A.R.L.
(RCS PONTOISE B 338 101 280)
98, Rue de la Belle Etoile, Z.I. Paris Nord II,
B.P. 50016, 95945 Roissy Charles de Gaulle
Cedex, France
Phone 01-48638989

ALPINE ITALIA S.p.A.
Viale C. Colombo 8, 20090 Trezzano
Sul Naviglio (MI), Italy
Phone 02-484781

ALPINE ELECTRONICS DE ESPAÑA, S.A.
Portal de Gamarra 36, Pabellón, 32
01013 Vitoria (Alava)-APDO 133, Spain
Phone 945-283588

ALPINE ELECTRONICS (BENELUX) GmbH
Leuvensesteenweg 510-B6,
1930 Zaventem, Belgium
Phone 02-725-13 15

Designed by ALPINE Japan
68-16909Z35-A

Contents

Operating Instructions

WARNING

WARNING 5
CAUTION 5
PRECAUTIONS 5
CAUTION 7

Getting Started

Accessory List 8
Turning Power On and Off 8
Detaching and Attaching the Front Panel 8
Initial System Start-Up 8
Adjusting Volume 8
Lowering Volume Quickly 8
Setting Time 9

Radio

Listening to Radio 9
Presetting Stations Manually 9
Presetting Stations Automatically 10
Tuning to Preset Stations 10

CD/MP3/WMA/AAC

Playback 10
Repeat Play 11
M.I.X. (Random Play) 11
Searching for CD Text 12
File/Folder Name Search
(concerning MP3/WMA/AAC) 12
Quick Search 12
About MP3/WMA/AAC 12

Sound Setting

Adjusting Subwoofer Level/Bass Level/Treble Level/Balance (Between Left and Right)/Fader (Between Front and Rear)/Defeat 14
Setting the Bass Control 14
Setting the Treble Control 14
Adjusting the High Pass Filter 15
Turning Loudness On/Off 15

Other Functions

Displaying the Text 15
Displaying Time 16
Using the Front AUX Input Terminal 16

SETUP

BLUETOOTH Setting

Setting the BLUETOOTH Connection
(BT IN) 17

Sound Customizing

Subwoofer On and Off 17
Setting the Subwoofer System 17

Visual Customizing

Changing Lighting Color
(CDE-126BT only) 17
Dimmer Control 17
Scroll Type Setting 18
Scroll Setting (TEXT SCR) 18
Demonstration 18

MP3/WMA/AAC

Playing MP3/WMA/AAC Data
(PLAY MODE) 18

External Device

Connecting to an External Amplifier
(POWER IC) 18
Setting the AUX+ SETUP Mode 19
Setting the AUX NAME mode 19

BT Hands-Free Calling

Setup Before Using 19
About BLUETOOTH 19
Before Using Hands-Free Function 19
How to connect to a BLUETOOTH compatible device (Pairing) 20
BLUETOOTH SETUP 20
BLUETOOTH Setup Operation 20
Setting the BLUETOOTH Device 20
Setting the Search Mode 20
Setting the Received Calls automatically (Auto Answer) 20
Deleting a BLUETOOTH Device from the list 20
Displaying the phone service provider name 21
Adjusting the volume for the microphone input 21
Selecting the output speaker 21
Displaying the firmware version 21
Updating the firmware 21
Hands-Free Phone Control 21
About the Hands-Free Phone 21
Answering a Call 21
Hanging up the Telephone 21
Redial Function 21
Calling 22
Redialing a Number In Outgoing History 22
Dialing a Number In Incoming History 22
Dialing a Number In Incoming Missed Call History 22
Dialing a Number In The Phone Book 22
Phone Book Alphabet Skip 22
Voice Dial Operation 22
Adjusting the volume when receiving a Call 23
Call Switching Operation 23

USB memory (Optional)

Playing MP3/WMA/AAC Files with the USB memory (Optional) 23
USB Memory Connection (Optional) 24
About MP3/WMA/AAC File of USB Memory 24

iPod/iPhone (Optional)

Playback 25
Searching for a desired Song 25
Quick Search 25
Direct Search Function 26
Select Playlist/Artist/Album/ Genre/Composer 26
Random Play Shuffle (M.I.X.) 26
Repeat Play 27
Displaying the Text 27

Information

In Case of Difficulty 27
Specifications 30

Installation and Connections

Warning 31
Caution 31
Precautions 31
Installation 32
Mounting the Microphone 32
Connections 33

LIMITED WARRANTY

Operating Instructions

WARNING

⚠WARNING

This symbol means important instructions. Failure to heed them can result in serious injury or death.

DO NOT OPERATE ANY FUNCTION THAT TAKES YOUR ATTENTION AWAY FROM SAFELY DRIVING YOUR VEHICLE.

Any function that requires your prolonged attention should only be performed after coming to a complete stop. Always stop the vehicle in a safe location before performing these functions. Failure to do so may result in an accident.

KEEP THE VOLUME AT A LEVEL WHERE YOU CAN STILL HEAR OUTSIDE NOISES WHILE DRIVING.

Excessive volume levels that obscure sounds such as emergency vehicle sirens or road warning signals (train crossings, etc.) can be dangerous and may result in an accident. LISTENING AT LOUD VOLUME LEVELS IN A CAR MAY ALSO CAUSE HEARING DAMAGE.

MINIMIZE DISPLAY VIEWING WHILE DRIVING.

Viewing the display may distract the driver from looking ahead of the vehicle and cause an accident.

DO NOT DISASSEMBLE OR ALTER.

Doing so may result in an accident, fire or electric shock.

USE ONLY IN CARS WITH A 12 VOLT NEGATIVE GROUND.

(Check with your dealer if you are not sure.) Failure to do so may result in fire, etc.

KEEP SMALL OBJECTS SUCH AS BATTERIES OUT OF THE REACH OF CHILDREN.

Swallowing them may result in serious injury. If swallowed, consult a physician immediately.

USE THE CORRECT AMPERE RATING WHEN REPLACING FUSES.

Failure to do so may result in fire or electric shock.

DO NOT BLOCK VENTS OR RADIATOR PANELS.

Doing so may cause heat to build up inside and may result in fire.

USE THIS PRODUCT FOR MOBILE 12V APPLICATIONS.

Use for other than its designed application may result in fire, electric shock or other injury.

DO NOT PLACE HANDS, FINGERS OR FOREIGN OBJECTS IN INSERTION SLOTS OR GAPS.

Doing so may result in personal injury or damage to the product.

⚠CAUTION

This symbol means important instructions. Failure to heed them can result in injury or material property damage.

HALT USE IMMEDIATELY IF A PROBLEM APPEARS.

Failure to do so may cause personal injury or damage to the product. Return it to your authorized Alpine dealer or the nearest Alpine Service Center for repairing.

⚠PRECAUTIONS

Product Cleaning

Use a soft dry cloth for periodic cleaning of the product. For more severe stains, please dampen the cloth with water only. Anything else has the chance of dissolving the paint or damaging the plastic.

Temperature

Be sure the temperature inside the vehicle is between +60°C (+140°F) and –10°C (+14°F) before turning your unit on.

Moisture Condensation

You may notice the CD playback sound wavering due to condensation. If this happens, remove the disc from the player and wait about an hour for the moisture to evaporate.

Damaged Disc

Do not attempt to play cracked, warped, or damaged discs. Playing a bad disc could severely damage the playback mechanism.

Maintenance

If you have problems, do not attempt to repair the unit yourself. Return it to your Alpine dealer or the nearest Alpine Service Station for servicing.

Never Attempt the Following

Do not grip or pull out the disc while it is being pulled back into the player by the automatic reloading mechanism.
Do not attempt to insert a disc into the unit when the unit power is off.



Inserting Discs

Your player accepts only one disc at a time for playback. Do not attempt to load more than one disc.
Make sure the label side is facing up when you insert the disc. “ERROR” will be displayed on your player if you insert a disc incorrectly. If “ERROR” continues to be displayed even though the disc has been inserted correctly, push the RESET switch with a pointed object such as a ballpoint pen.
Playing a disc while driving on a very bumpy road may result in skips, but this will not scratch the disc or damage the player.

New Discs

To prevent the CD from jamming, “ERROR” is displayed if discs with irregular surfaces are inserted or if discs are inserted incorrectly. When a new disc is ejected immediately after initial loading, use your finger to feel around the inside of the center hole and outside edge of the disc. If you feel any small bumps or irregularities, this could inhibit proper loading of the disc. To remove the bumps, rub the inside edge of the hole and outside edge of the disc with a ballpoint pen or other such instrument, then insert the disc again.



Irregular Shaped Discs

Be sure to use round shape discs only for this unit and never use any special shape discs.
Use of special shape discs may cause damage to the mechanism.

Installation Location

Make sure this unit will not be installed in a location subjected to:

- Direct sun and heat
- High humidity and water
- Excessive dust
- Excessive vibrations

Correct Handling

Do not drop the disc while handling. Hold the disc so you will not leave fingerprints on the surface. Do not affix tape, paper, or gummed labels to the disc. Do not write on the disc.



Disc Cleaning

Fingerprints, dust, or soil on the surface of the disc could cause the CD player to skip. For routine cleaning, wipe the playing surface with a clean, soft cloth from the center of the disc to the outer edge. If the surface is heavily soiled, dampen a clean, soft cloth in a solution of mild neutral detergent before cleaning the disc.

Disc Accessories

There are various accessories available on the market for protecting the disc surface and improving sound quality. However, most of them will influence the thickness and/or diameter of the disc. Using such accessories can cause the disc to be out of standard specifications and may create operational problems. We recommend not using these accessories on discs played in Alpine CD players.

On handling Compact Discs (CD/CD-R/CD-RW)

- Do not touch the surface.
- Do not expose the disc to direct sunlight.
- Do not affix stickers or labels.
- Clean the disc when it is dusty.
- Make sure that there are no bumps around the disc.
- Do not use commercially available disc accessories.

Do not leave the disc in the car or the unit for a long time. Never expose the disc to direct sunlight. Heat and humidity may damage the CD and you may not be able to play it again.

To customers using CD-R/CD-RW

- If a CD-R/CD-RW cannot be played back, make sure the last recording session was closed (finalized).
- Finalize the CD-R/CD-RW if necessary, and attempt playback again.

About media that can be played

The following table shows which discs can be played on which models.

	CD	CD-TEXT	MP3	WMA	AAC
CDE-126BT	○	○	○	○	○
CDE-125BT	○	○	○		

Use only compact discs with the label side showing the CD logo marks below.

If you use unspecified compact discs, correct performance cannot be guaranteed.
You can play CD-Rs (CD-Recordables)/CD-RWs (CD-ReWritables) which have been recorded only on audio devices. You can also play CD-Rs/CD-RWs containing MP3/WMA/AAC formatted audio files.

- Some of the following CDs may not play on this unit:
  Flawed CDs, CDs with fingerprints, CDs exposed to extreme temperatures or sunlight (e.g., left in the car or this unit), CDs recorded under unstable conditions, CDs on which a recording failed or a re-recording was attempted, copy-protected CDs which do not conform to the audio CD industry standard.
- Use discs with MP3/WMA/AAC files written in a format compatible with this unit. For details, see pages 12-13.
- ROM data other than audio files contained in a disc will not produce sound when played back.

Protecting the USB connection terminal

- Only USB flash memory devices can be connected to the USB connection terminal on this unit. Correct performance using other USB products cannot be guaranteed. A USB hub is not supported.
- Do not connect a USB memory over 20 mm wide. Also, avoid connecting USB memory and Front Aux at the same time.
- If a USB device is inserted in the unit, it projects out and may be a danger while driving. Use a commercially available USB extension cable, and connect it in a safe way.
- Depending on the connected USB memory device, the unit may not function or some functions may not be performed.
- The audio file format that can be played back on the unit is MP3/WMA/AAC.
- Artist/song name, etc., can be displayed, however characters may not be correctly displayed.

⚠CAUTION

Alpine accepts no responsibility for lost data, etc., even if data, etc. is lost while using this product.

On Handling USB Memory

- To prevent malfunction or damage, note the following points.
  Read the USB memory Owner's Manual thoroughly.
  Do not touch the terminals by hand or metal.
  Do not subject USB memory to excessive shock.
  Do not bend, drop, disassemble, modify or soak in the water.
- Avoid usage or storage in the following locations:
  Anywhere in the car exposed to direct sunlight or high temperatures.
  Anywhere the possibility of high humidity or corrosive substances are present.
- Fix the USB memory in a location where driver operation will not be hindered.
- USB memory may not function correctly at high or low temperature.
- The USB flash memory supports only 512 or 2,048 bytes per sector.
- Use only certified USB memory. Note that even certified USB memory, may not function correctly depending on its type or state.
- USB memory function is not guaranteed. Use USB memory according to the terms of agreement.
- Depending on the settings of the USB memory type, memory state or encoding software, the unit may not play back or display properly.
- A file that is copy-protected (copyright protection) cannot be played back.
- USB memory may take time to start playback. If there is a particular file other than audio in the USB memory, it may take considerable time before the file is played back or searched.
- The unit can play back "mp3", "wma" or "m4a" file extensions.
- Do not add the above extensions to a file other than audio data. This non-audio data will not be recognized. The resulting playback may contain noise that can damage speakers and/or amplifiers.
- It is recommended to back up important data on a personal computer.
- Do not remove the USB device while playback is in progress. Change SOURCE to something other than USB, then remove the USB device to prevent possible damage to its memory.

- *iPhone, iPod, iPod classic, iPod nano, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.*
- *"Made for iPod," and "Made for iPhone," mean that an electronic accessory has been designed to connect specifically to iPod, or iPhone, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.*
- *Windows Media and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.*
- *The BLUETOOTH® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Alpine Electronics, Inc. is under license.*
- *"MPEG Layer-3 audio coding technology licensed from Fraunhofer IIS and Thomson."*
- *"Supply of this product only conveys a license for private, non-commercial use and does not convey a license nor imply any right to use this product in any commercial (i.e. revenue-generation) real time broadcasting (terrestrial, satellite, cable and/or any other media), broadcasting/streaming via internet, intranets and/or other networks or in other electronic content distribution systems, such as pay-audio or audio-on-demand applications. An independent license for such use is required. For details, please visit http://www. mp3licensing.com"*

Getting Started



Accessory List

- **Head unit 1**
- **Power cable 1**
- **Interface cable for iPod (CDE-126BT only) 1**
- **Microphone (4m) 1**
- **Mounting sleeve 1**
- **Carrying case 1**
- **Bracket key 2**
- **Screw (M5 × 8) 4**
- **Owner's Manual ..... 1 set**

Turning Power On and Off

Press SOURCE/⏻ to turn on the unit.

- *The unit can be turned on by pressing any other button except ⏏ and ⏏ (Release).*

Press and hold SOURCE/⏻ for at least 2 seconds to turn off the unit.

- *The first time power is turned on, the volume will start from level 12.*

Detaching and Attaching the Front Panel

Detaching

1. **Turn off the unit power.**
2. **Press ⏏ (Release) at the lower left side until the front panel pops out.**
3. **Grasp the left side of the front panel and pull it out.**



- *The front panel may become hot in normal usage (especially the connector terminals on the back of the front panel). This is not a malfunction.*
- *To protect the front panel, place it in the supplied carrying case.*
- *When detaching the front panel, do not apply excessive force as it may result in malfunction.*

Attaching

1. **Insert the right side of the front panel into the main unit. Align the groove on the front panel with the projections on the main unit.**
2. **Push the left side of the front panel until it locks firmly into the main unit.**



- *Before attaching the front panel, make sure that there is no dirt or dust on the connector terminals and no foreign object between the front panel and the main unit.*
- *Attach the front panel carefully, holding the sides of the front panel to avoid pushing buttons by mistake.*

Initial System Start-Up

Be sure to press the RESET switch when using the unit for the first time, after changing the car battery, etc.

1. **Turn off the unit power.**
2. **Remove the detachable front panel.**
3. **Press RESET with a ballpoint pen or similar pointed object.**



Adjusting Volume

Turn the Rotary encoder until the desired sound is obtained.

Lowering Volume Quickly

Activating the Audio Mute function will instantly lower the volume level by 20 dB.

Press ⮌/MUTE to activate the MUTE mode.
The audio level will decrease by about 20 dB.

Pressing ⮌/MUTE again will bring the audio back to its previous level.

Setting Time

1 **Press and hold SOUND/SETUP for at least 2 seconds to activate the SETUP mode.**

2 **Turn the Rotary encoder to select the CLOCK ADJ mode, and then press ▶/❙❙ /ENT.**
The time indication will blink.

3 **Turn the Rotary encoder to adjust the hours while the time indication is blinking.**

4 **When the hour has been adjusted, press ▶/❙❙ /ENT.**

5 **Turn the Rotary encoder to adjust the minutes while the time indication is blinking.**

6 **Press and hold SOUND/SETUP for at least 2 seconds to return to normal mode.**

- *To synchronize the clock to another clock/watch or radio time announcement, press and hold ▶/❙❙ /ENT for at least 2 seconds after setting the "hour." Minutes will reset to "00". If the display shows over "30" minutes when you do this, the time will advance one hour.*
- *Pressing ⮌/MUTE will return to the previous mode.*
- *If no operation is performed for 60 seconds, the unit will return to normal mode automatically.*

Controllable with Remote Control

This unit can be controlled with an optional Alpine remote control. For details, consult your Alpine dealer. Point the optional remote control transmitter at the remote-control sensor.

Remote control sensor



Radio



Listening to Radio

1 **Press SOURCE/⏻ to select TUNER mode.**

2 **Press BAND repeatedly until the desired radio band is displayed.**

F1 (FM1) → F2 (FM2) → AM → F1 (FM1)

3 **Press TUNE/A.ME to select the tuning mode.**

DX SEEK (Distance mode) → SEEK (Local mode) → OFF (Manual mode) → DX SEEK

- *The initial mode is Distance mode.*

Distance mode:
Both strong and weak stations will be automatically tuned in (Automatic Seek Tuning).

Local mode:
Only strong stations will be automatically tuned in (Automatic Seek Tuning).

Manual mode:
The frequency is manually tuned in steps (Manual tuning).

4 **Press |◀◀ or ▶▶| to tune in the desired station.**
Holding down |◀◀ or ▶▶| will change the frequency continuously.

Presetting Stations Manually

1 **Select the radio band and tune in a desired radio station you wish to store in the preset memory.**

2 **Press and hold, for at least 2 seconds, any one of the preset buttons (1 through 6) into which you wish to store the station.**
The selected station is stored.
The display shows the band, preset number and station frequency memorized.

- *A total of 18 stations can be stored in the preset memory (6 stations for each band; FM1, FM2 and AM).*
- *If you store a station in a preset memory which already has a station, the current station will be cleared and replaced with the new station.*

Presetting Stations Automatically

1 **Press BAND repeatedly until the desired radio band is displayed.**

2 **Press and hold TUNE/A.ME for at least 2 seconds.**
The frequency on the display continues to change while the automatic memory is in progress. The tuner will automatically seek and store 6 strong stations in the selected band. They will be stored into preset buttons 1 to 6 in order of signal strength.
When the automatic memory has been completed, the tuner goes to the station stored in preset location No.1.

- *If no stations are stored, the tuner will return to the original station you were listening to before the auto memory procedure began.*

Tuning to Preset Stations

1 **Press BAND repeatedly until the desired band is displayed.**

2 **Press any one of the station preset buttons (1 through 6) that has your desired radio station in memory.**
The display shows the band, preset number and frequency of the station selected.

CD/MP3/WMA/AAC



Playback

The following table shows which discs can be played on which models.

	CD	CD-TEXT	MP3	WMA	AAC
CDE-126BT	○	○	○	○	○
CDE-125BT	○	○	○		

1 **Insert a disc with the label side facing up.**
The disc will be pulled into the unit automatically, and the "⊙" indicator lights up .



When a disc is already inserted, press SOURCE/⏻ to switch to the DISC mode.

The mode will change every time the button is pressed.

TUNER → DISC → USB AUDIO → iPod*[1]/AUX+*[2] → AUX*[3] → TUNER

*[1] *Displayed only when the iPod/iPhone is connected and AUX+ SETUP is set to OFF, refer to "Setting the AUX+ SETUP Mode" (page 19).*
*[2] *Displayed only when the AUX+ SETUP is set to ON, refer to "Setting the AUX+ SETUP Mode" (page 19).*
*[3] *Refer to "Using the Front AUX Input Terminal" (page 16).*

2 **While playing back MP3/WMA/AAC, press 1 ◄ or ► 2 to select the desired folder.**
Pressing and holding 1 ◄ or ► 2 will change folders continuously.

3 Press ⏮ or ⏭ to select the desired track (file).

Returning to the beginning of the current track (file):
Press ⏮.

Fast backward:
Press and hold ⏮.

Advancing to the beginning of the next track (file):
Press ⏭.

Fast forward:
Press and hold ⏭.

4 To pause playback, press ▶/❚❚/ENT.
Pressing ▶/❚❚/ENT again will resume playback.

5 To eject the disc, press ⏏ .

- *Do not remove a CD during its eject cycle. Do not load more than one disc at a time. A malfunction may result from doing either.*
- *If the CD does not eject, press and hold ⏏ for at least 2 seconds.*
- *The "⏏" indicator lights up when a disc is inserted.*
- *Three-inch (8 cm) CDs cannot be used.*

CDE-126BT (compatible with MP3/WMA/AAC)/
CDE-125BT (compatible with MP3):
- *The CD-player can play discs containing audio data, MP3 data, WMA data and AAC data.*
- *WMA format files that are protected by DRM (Digital Rights Management), AAC format files that have been purchased from the iTunes Store and files that are copy-protected (copyright protection) cannot be played back on this unit.*
- *The track display for MP3/WMA/AAC data playback is the file numbers recorded on the disc.*
- *The playback time may not be correctly displayed when a VBR (Variable Bit Rate) recorded file is played back.*

MP3/WMA/AAC Play Display
The folder number and file number will be displayed as described below.



- *Press **VIEW** to switch the display. See "Displaying the Text" (page 15) for information about display switching.*

Repeat Play

Press 🔁 4 to play back repeatedly the track being played.
The track (file) will be played repeatedly.

Press 🔁 4 again and select off to deactivate repeat play.

CD mode :



MP3/WMA/AAC mode :



M.I.X. (Random Play)

Press 5 🔀 in the play or pause mode.
The tracks (files) on the disc will be played back in random sequence.

To cancel M.I.X. play, press 5 🔀 again.

CD mode :

MP3/WMA/AAC mode :



* *In the USB mode, all files stored in the USB memory are played back in random sequence, and the "🔀" indicator lights up.*

Searching for CD Text

On discs utilizing CD Text, songs can be searched and played by using their recorded titles. For discs without CD Text, searches are made using the track numbers associated with each song.

1 **Press 🔍/ESC during play.**
This will set the search mode, and the "🔍" indicator lights up.

2 **Turn the Rotary encoder to select the desired track, and then press ▶/❚❚/ENT.**
This will play the selected track.

- *Press and hold 🔍/ESC for at least 2 seconds in the search mode to cancel. Or, the search mode is canceled if no operation is performed for 10 seconds.*
- *When CD Text Search is made during M.I.X. play, the M.I.X. play mode will be canceled.*

File/Folder Name Search (concerning MP3/WMA/AAC)

Folder and file names may be searched and displayed during playback.

1 **During MP3/WMA/AAC playback, press 🔍/ESC to activate the search mode.**
The "🔍" indicator lights up.

2 **Turn the Rotary encoder to select Folder Name Search mode or File Name Search mode, and then press ▶/❚❚/ENT.**

Folder Name Search mode

3 **Turn the Rotary encoder to select the desired folder.**

4 **Press and hold ▶/❚❚/ENT for at least 2 seconds to play back the first file in the selected folder.**

- *Press and hold 🔍/ESC for at least 2 seconds in the search mode to cancel. Or, the search mode is canceled if no operation is performed for 10 seconds.*
- *To search for files in the Folder Name Search mode, press ▶/❚❚/ENT. Files in the folder may be searched.*
- *Press ⮌/MUTE to exit Folder Name Search mode in step 3 in order to select File Name Search mode.*
- *The root folder is displayed as "ROOT".*
- *When Folder Name Search is made during M.I.X. play, the M.I.X. play mode will be canceled.*

File Name Search mode

3 **Press 1 ◀ or ▶ 2 to select another Folder.**

4 **Select the desired file by turning the Rotary encoder.**

5 **Press ▶/❚❚/ENT to play back the selected file.**

- *Press and hold 🔍/ESC for at least 2 seconds in the search mode to cancel. Or, the search mode is canceled if no operation is performed for 10 seconds.*
- *Press ⮌/MUTE in the search mode to return to the previous mode.*
- *When File Name Search is made during M.I.X. play, the M.I.X. play mode will be canceled.*

Quick Search

You can search for tracks (files).

1 **Press and hold 🔍/ESC for at least 2 seconds in the CD/MP3/WMA/AAC mode to activate Quick Search mode.**
The "🔍" indicator lights up.

2 **Turn the Rotary encoder to select a desired track (file).**
The selected track is played back immediately.

- *Press and hold 🔍/ESC for at least 2 seconds in the search mode to cancel. Or, the search mode is canceled if no operation is performed for 10 seconds.*

About MP3/WMA/AAC

CAUTION

Except for private use, duplicating audio data (including MP3/WMA/AAC data) or distributing, transferring, or copying it, whether for free or for a fee, without permission of the copyright holder is strictly prohibited by the Copyright Act and by international treaty.

What is MP3?

MP3, whose official name is "MPEG-1 Audio Layer 3," is a compression standard prescribed by the ISO, the International Standardization Organization and MPEG which is a joint activity institution of the IEC.

MP3 files contain compressed audio data. MP3 encoding is capable of compressing audio data at extremely high ratios, reducing the size of music files to as much as one-tenth their original size. This is achieved while still maintaining near CD quality. The MP3 format realizes such high compression ratios by eliminating the sounds that are either inaudible to the human ear or masked by other sounds.

What is WMA?

WMA, or "Windows Media™ Audio," is compressed audio data. WMA is similar to MP3 audio data and can achieve CD quality sound with small file sizes.

What is AAC?

AAC is the abbreviation for "Advanced Audio Coding," and is a basic format of audio compression used by MPEG2 or MPEG4.

Method for creating MP3/WMA/AAC files

Audio data is compressed using software with MP3/WMA/AAC codecs. For details on creating MP3/WMA/AAC files, refer to the user's manual for that software.
MP3/WMA/AAC files that are playable on this device have the file extensions "mp3" / "wma" / "m4a". Files with no extension cannot be played back (WMA ver. 7.1, 8 and 9 are supported). Protected files are not supported, neither are raw AAC files (using the ".aac" extension).

There are many different versions of the AAC format. Confirm that the software being used conforms to the acceptable formats listed above. It's possible that the format may be unplayable even though the extension is valid.
Playback of AAC files encoded by iTunes is supported.

Supported playback sampling rates and bit rates

MP3
Sampling rates: 48 kHz, 44.1 kHz, 32 kHz, 24 kHz, 22.05 kHz, 16 kHz, 12 kHz, 11.025 kHz, 8 kHz
Bit rates: 8 - 320 kbps

WMA
Sampling rates: 48 kHz, 44.1 kHz, 32 kHz
Bit rates: 48 - 192 kbps

AAC
Sampling rates: 48 kHz, 44.1 kHz, 32 kHz, 24 kHz, 22.05 kHz, 16 kHz, 12 kHz, 11.025 kHz, 8 kHz
Bit rates: 16 - 320 kbps

This device may not play back correctly depending on sampling rates.

ID3 tags/WMA tags

This device supports ID3 tag v1 and v2, and WMA tag.
If tag data is in an MP3/WMA/AAC file, this device can display the title (track title), artist name, and album name ID3 tag/WMA tag data.

This device can only display single-byte alphanumeric characters (up to 30 for ID3 tags and up to 15 for WMA tags) and the underscore. For non-supported characters, "NO SUPPORT" is displayed.
If information contains characters other than ID3 tag information, the audio file may not be played back.
The tag information may not be correctly displayed, depending on the contents.

Producing MP3/WMA/AAC discs

MP3/WMA/AAC files are prepared, then written to a CD-R or CD-RW using CD-R writing software. A disc can hold up to 510 files/folders (including Root Folders), and the maximum number of folders is 255.
Playback may not be performed if a disc exceeds the limitations described above.

Media supported

The media that this device can play back are CD-ROMs, CD-Rs, and CD-RWs.

Corresponding File Systems

This device supports discs formatted with ISO9660 Level 1 or Level 2.

Under the ISO9660 standard, there are some restrictions to remember.

The maximum nested folder depth is 8 (including the root directory). The number of characters for a folder/file name is limited.

Valid characters for folder/file names are letters A-Z (all caps), numbers 0-9, and '_' (underscore).

This device also can play back discs in Joliet, Romeo, etc., and other standards that conform to ISO9660. However, sometimes the file names, folder names, etc., are not displayed correctly.

Formats supported

This device supports CD-ROM XA, Mixed Mode CD, Enhanced CD (CD-Extra) and Multi-Session.
This device cannot correctly play back discs recorded with Track At Once or packet writing.

Order of files

Files are played back in the order that the writing software writes them to the disc. Therefore, the playback order may not be what is expected. Verify the writing order in the software's documentation. The playback order of the folders and files is as follows.



* *The folder No./ folder Name will not be displayed if no file is contained in the folder.*

Terminology

Bit rate

This is the "sound" compression rate specified for encoding. The higher the bit rate, the higher the sound quality, but also the larger the files.

Sampling rate

This value shows how many times per second the data is sampled (recorded). For example, music CDs use a sampling rate of 44.1 kHz, so the sound is sampled (recorded) 44,100 times per second. The higher the sampling rate, the higher the sound quality, but also the larger the volume of data.

Encoding

Converting music CDs, WAVE (AIFF) files, and other sound files into the specified audio compression format.

Tag

Song information such as track titles, artist names, album names, etc., written into MP3/WMA/AAC files.

Root folder

The root folder (or root directory) is found at the top of the file system. The root folder contains all folders and files. It is created automatically for all burned discs.

Sound Setting



Adjusting Subwoofer Level/Bass Level/ Treble Level/Balance (Between Left and Right)/Fader (Between Front and Rear)/ Defeat

1 Press Rotary encoder (AUDIO) repeatedly to choose the desired mode.

Each press changes the mode as follows:

SUBWOOFER* → BASS LEVEL → TRE LEVEL → BALANCE → FADER → DEFEAT → VOLUME → SUBWOOFER

Subwoofer : +0 ~ +15
Bass level: –7 ~ +7
Treble level: –7 ~ +7
Balance : L15 ~ R15
Fader : R15 ~ F15
Defeat : ON/OFF
Volume : 0 ~ 35

- *If no operation is performed for 5 seconds after selecting the SUBWOOFER, BASS LEVEL, TRE LEVEL, BALANCE, FADER or DEFEAT mode, the unit automatically returns to normal mode.*

* *When the subwoofer mode is set to OFF, its level cannot be adjusted.*

2 Turn the Rotary encoder until the desired sound is obtained in each mode.

By setting DEFEAT ON, previously adjusted settings of BASS LEVEL and TRE LEVEL will return to the factory defaults.

Setting the Bass Control

You can change the Bass Frequency emphasis to create your own tonal preference.

1 Press SOUND/SETUP repeatedly to select the BASS mode.

BASS → TREBLE → HPF → BASS

Setting the Bass Center Frequency

2-1 Press BAND to select the desired bass center frequency.

80 Hz → 100 Hz → 200 Hz → 60 Hz → 80 Hz

Emphasizes the displayed bass frequency ranges.

Setting the Bass Bandwidth

2-2 Press SOURCE/⏻ to select the desired bass bandwidth.

→ 1 → 2 → 3 → 4 →
(Narrow) ←·····→ (Wide)

Changes the boosted bass bandwidth to wide or narrow. A wider setting will boost a wide range of frequencies above and below the center frequency. A narrower setting will boost only frequencies near the center frequency.

Setting the Bass Level

2-3*1 Turn the Rotary encoder to select the desired bass level (–7~+7).

You can emphasize or weaken the bass level.

3 Press and hold /ESC for at least 2 seconds to return to normal mode.

- *If no operation is performed for 15 seconds, the unit will return to normal mode automatically.*
- *The bass level settings will be individually memorized for each source (FM, AM, CD, etc.) until the setting is changed. The bass frequency and bass bandwidth settings adjusted for one source are effective for all other sources (FM, AM, CD, etc.).*
- *The function is inoperable when DEFEAT is set to ON.*

*1 *The adjustment can also be made by pressing **Rotary encoder**. Refer to "Adjusting Subwoofer Level/Bass Level/Treble Level/ Balance (Between Left and Right)/Fader (Between Front and Rear)/ Defeat" (page 14).*

Setting the Treble Control

You can change the Treble Frequency emphasis to create your own tonal preference.

1 Press SOUND/SETUP repeatedly to select the TREBLE mode.

BASS → TREBLE → HPF → BASS

Setting the Treble Center Frequency

2-1 Press BAND to select the desired treble center frequency.

10.0 kHz → 12.5 kHz → 15.0 kHz → 17.5 kHz → 10.0 kHz

Emphasizes the displayed treble frequency ranges.

Setting the Treble Level

2-2[*2] **Turn the Rotary encoder to select the desired treble level (–7~+7).**
You can emphasize the treble level.

3 Press and hold 🔍/ESC for at least 2 seconds to return to normal mode.

- *If no operation is performed for 15 seconds, the unit will return to normal mode automatically.*
- *The treble level settings will be individually memorized for each source (FM, AM, CD, etc.) until the setting is changed. The Treble frequency settings adjusted for one source are effective for all other sources (FM, AM, CD, etc.).*
- *The function is inoperable when DEFEAT is set to ON.*

*[*2] The adjustment can also be made by pressing **Rotary encoder.** Refer to "Adjusting Subwoofer Level/Bass Level/Treble Level/ Balance (Between Left and Right)/Fader (Between Front and Rear)/ Defeat" (page 14).*

Adjusting the High Pass Filter

The High Pass Filter on this unit can be adjusted to suit your personal taste.

1 Press SOUND/SETUP repeatedly to select the HPF mode.

BASS → TREBLE → HPF → BASS

2 Turn the Rotary encoder to select the desired HPF frequency.

OFF ↔ 60 Hz ↔ 80 Hz ↔ 100 Hz

All frequencies above the selected cutoff are output.

3 Press and hold 🔍/ESC for at least 2 seconds to return to normal mode.

- *If no operation is performed for 15 seconds, the unit will return to normal mode automatically.*
- *The function is inoperable when DEFEAT is set to ON.*

Turning Loudness On/Off

Loudness introduces a special low- and high-frequency emphasis at low listening levels. This compensates for the ear's decreased sensitivity to bass and treble sound.

Press and hold Rotary encoder (LOUD) for at least 2 seconds to activate or deactivate the loudness mode.

- *The function is inoperable when DEFEAT is set to ON.*

Other Functions



Displaying the Text

Text information, such as the disc name and the track name, will be displayed if playing a CD text compatible disc. It is also possible to display the folder name, the file name and the tag, etc., while playing MP3/WMA/AAC files.

Press VIEW.
The display will change every time the button is pressed.

- *When the TEXT SCR is set to SCR MANU, press and hold **VIEW** for at least 2 seconds, the current text will be scrolled one time (except Radio mode).*

The display in Radio mode:

FREQUENCY → CLOCK → FREQUENCY

The display in CD mode:

TRACK NO./ELAPSED TIME → TRACK NO./CLOCK → TEXT (DISC NAME)*[1] → TEXT (TRACK NAME)*[1] → TRACK NO./ELAPSED TIME

The display in MP3/WMA/AAC mode:

FILE NO./ELAPSED TIME → FOLDER NO./FILE NO. → FILE NO./CLOCK → FOLDER NAME → FILE NAME → ARTIST NAME*[2] → ALBUM NAME*[2] → SONG NAME*[2] → FILE NO./ELAPSED TIME

The display in AUX mode:

AUX NAME → AUX NAME/CLOCK → AUX NAME

[1] Displayed during playback of a disc with CD text.
[2] ID3 tag/WMA tag
If an MP3/WMA/AAC file contains ID3 tag/WMA tag information, the ID3 tag/WMA tag information is displayed (e.g., song name, artist name, and album name). All other tag data is ignored.

About the indication display

When displaying Text, the following indicators are lit according to the mode.

Indicator/ Mode	CD Mode	MP3/WMA/AAC/ USB AUDIO Mode	iPod/iPhone Mode
	—	Folder Name*2 being displayed	—
	—	Artist Name*1 being displayed	Artist Name*1 being displayed
	Text (Disc Name*3) being displayed	Album Name*1 being displayed	Album Name*1 being displayed
	Text (Track Name*3) being displayed	Song Name*1/ File Name being displayed	Song Name*1 being displayed

*1 *Tag information*
If there is no tag information, "ARTIST"/"ALBUM"/"SONG" is displayed.
*2 *The root folder is displayed as "ROOT".*
*3 *If there is no Text (Disc Name or Track Name), "DISC TEXT"/ "TRACK TEXT" is displayed.*

About "Text"

Text:

Text compatible CDs contain text information such as the disc name and track name. Such text information is referred to as "text."

- *Some characters may not be displayed correctly with this device, depending on the character type.*
- *"NO SUPPORT" is displayed when the desired text information cannot be displayed on this unit.*
- *The text or tag information may not be correctly displayed, depending on the contents.*

Displaying Time

Press VIEW repeatedly until the time is displayed.
Each press changes the display.
For details, see "Displaying the Text" (page 15).

- *Selecting any tuner or CD function while in the clock priority mode will interrupt the time display momentarily. The function selected will be displayed for about 5 seconds before the time returns to the display.*

Using the Front AUX Input Terminal

Connect a portable music player, etc. by simply connecting it to the input on the front panel. An optional adapter cable is required (standard RCA to 3.5ø mini-phono plug or 3.5ø to 3.5ø mini phono plug).

Press SOURCE/⏻, and select the AUX mode to listen to the portable device.

TUNER → DISC → USB AUDIO → iPod*1/AUX+*2 → AUX → TUNER

*1 *Displayed only when the iPod/iPhone is connected and AUX+ SETUP is set to OFF, refer to "Setting the AUX+ SETUP Mode" (page 19).*
*2 *Displayed only when the AUX+ SETUP is set to ON, refer to "Setting the AUX+ SETUP Mode" (page 19).*


Portable player, etc.
Main unit
PHONE
L — AUDIO OUT — R
or
Optional adapter cable (RCA pin plugs [red, white] 3.5ø miniplugs) or (3.5ø miniplugs)

SETUP

You can flexibly customize the unit to suit your own preferences and usage. From the SETUP menu, Sound Customizing, Visual Customizing, etc., can be modified.



Use steps 1 to 4 to select one of the SETUP modes to modify. See the applicable section below for details about the selected SETUP item.

1 Press and hold SOUND/SETUP for at least 2 seconds to activate the SETUP mode.

2 Turn the Rotary encoder to select the desired SETUP menu, and then press ►/❙❙ /ENT.
(e.g. Select SUBWOOFER)

BT IN ↔ CLOCK ADJ*1 ↔ PLAY MODE ↔ AUX+ SETUP ↔ AUX+ NAME*2 ↔ AUX NAME ↔ POWER IC ↔ DEMO ↔ SUBWOOFER ↔ SUBW SYS*3 ↔ ILLUMINATI*4 ↔ DIMMER ↔ SCROLLTYPE ↔ TEXT SCR ↔ BT IN

*1 *Refer to "Setting Time" (page 9).*
*2 *Displayed only when AUX+ SETUP is ON.*
*3 *Displayed only when SUBWOOFER is ON.*
*4 *CDE-126BT only.*

3 Turn the Rotary encoder to change the setting.
(e.g. Select SUBW ON or SUBW OFF.)

4 Press and hold SOUND/SETUP for at least 2 seconds to return to normal mode.

- *Press ⮌/MUTE to return to the previous mode.*
- *If no operation is performed for 60 seconds, the unit will return to normal mode automatically.*

BLUETOOTH Setting

Setting the BLUETOOTH Connection (BT IN)

BT ADAPTER (Initial setting) / BT OFF

With BLUETOOTH technology, you can place a hands-free call by a BLUETOOTH-equipped mobile phone.

Set ADAPTER when the BLUETOOTH function is used. For details on the set up procedure, refer to "BLUETOOTH SETUP" on page 20.

- *If the mobile phone compatible with the Voice Dial function is connected, the Voice Dial function can be used.*

Sound Customizing

Subwoofer On and Off

SUBW ON (Initial setting) / SUBW OFF

When the subwoofer is on, perform the steps below to adjust the subwoofer output level.

1 In the normal mode, press Rotary encoder (AUDIO) repeatedly to select the SUBWOOFER mode.

SUBWOOFER → BASS LEVEL → TRE LEVEL → BALANCE → FADER → DEFEAT → VOLUME → SUBWOOFER

2 Adjust the level by turning the Rotary encoder.

Setting the Subwoofer System

SUBW SYS 1 (Initial setting) / SUBW SYS 2

Select either SYS 1 or SYS 2 for the desired subwoofer effect.

SUBW SYS 1: Subwoofer level changes according to the main volume setting.

SUBW SYS 2: Subwoofer level change is different from the main volume setting. For example, even at low volume settings, the subwoofer is still audible.

Visual Customizing

Changing Lighting Color (CDE-126BT only)

ILUM TYPE1 (Initial setting) / TYPE2

You can change the lighting color of the following four buttons. SOURCE/⏻, BAND, ⏮, ⏭.

TYPE1: When the color of the four buttons is blue, the color of the other is blue.

TYPE2: When the color of the four buttons is red, the color of the other is red.

Dimmer Control

DIM AUTO (Initial setting) / DIM MANUAL

Set the DIMMER control to AUTO to decrease the illumination brightness of the unit with the head lights of the vehicle ON. This mode is useful if you feel the unit's backlighting is too bright at night.

- *The function is inoperable when the ILLUMINATI is set to other than TYPE1 for CDE-126BT, refer to "Changing Lighting Color (CDE-126BT only)" on page 17.*

Scroll Type Setting

SCR TYPE1 / SCR TYPE2 (Initial setting)

Choose from two scrolling methods.
Select the type you prefer.

SCR TYPE1: The characters scroll from right to left, a single character at a time.

SCR TYPE2: Words are built up from left to right, a single character at a time. When the display is filled, it is cleared and the remaining words are displayed the same way until all words of the title have been shown.

Scroll Setting (TEXT SCR)

SCR AUTO / SCR MANU (Initial setting)

This CD player can scroll the disc and track names recorded on CD-TEXT discs, as well as the text information of MP3/WMA/AAC files, folder names and tags.

SCR AUTO: The CD text information, the text information of folder and file names, and the tags are scrolled automatically.

SCR MANU: The display is scrolled when a disc is loaded or when a track is changed, etc.

- *The unit scrolls CD text names, folder names, file names or tag display.*

Demonstration

DEMO ON / DEMO OFF (Initial setting)

This unit has a demonstration feature for the display.

- *To quit Demo mode, set to DEMO OFF.*

MP3/WMA/AAC

Playing MP3/WMA/AAC Data (PLAY MODE)

CD-DA (Initial setting) / CDDA/MP3

This unit can play back CDs containing both CD and MP3/WMA/AAC data (created in Enhanced CD (CD Extra) format). However, in some situations, playback of an enhanced CD may be difficult. In this case, you can select playback of a single session only, containing the CD data. When a disc contains both CD and MP3/WMA/AAC data, playback starts from the CD data portion of the disc.

CD-DA: Only the CD data in Session 1 can be played back.

CDDA/MP3: CD data, MP3/WMA/AAC files in mixed mode, and multi-session discs can be played back.

- *Perform this setting before inserting a disc. If a disc has already been inserted, remove it first.*

External Device

Connecting to an External Amplifier (POWER IC)

POW ON (Initial setting) / POW OFF

When an external amplifier is connected, sound quality can be improved by stopping the power supply of the built-in amplifier.

POW OFF: Use this mode when the line output of this unit is used to drive an external amplifier. In this setting, the head unit's internal amplifier is turned OFF and cannot drive speakers.

CDE-126BT:



CDE-125BT:



POW ON: The speakers are driven by the built-in amplifier.



- *No sound is produced by the system when the power output is set to OFF.*

Setting the AUX+ SETUP Mode

AUX+ ON / AUX+ OFF (Initial setting)

An external device (such as a portable music player) can be connected to the Full Speed connector of this unit. A conversion cable (KCE-237B) for building up the AUX IN (optional) is required.

A portable music device and an iPod/iPhone cannot be connected to the Full Speed connector at the same time.

AUX+ ON: Set to ON when a portable device is connected. If SOURCE/⏻ is pressed and AUX+ is selected, the sound of the portable device is input to the unit.

AUX+ OFF: Set to OFF when an iPod/iPhone is connected.

You can change the AUX+ name display when AUX+ SETUP is set to ON. Press ▶/II /**ENT** when AUX+ SETUP is set to ON, and select AUX+ NAME by turning the **Rotary encoder**, then press ▶/II /**ENT**. After that, turn the **Rotary encoder** to select the desired AUX+ name.

Setting the AUX NAME mode

AUXILIARY*[1] *(Initial setting) / TV / DVD / PORTABLE*[2] */ GAME

You can change the AUX NAME display in the SETUP mode.

[1] After the setting is completed, AUX is displayed on the unit.
[2] After the setting is completed, PMD is displayed on the unit.

BT Hands-Free Calling



Setup Before Using

About BLUETOOTH

BLUETOOTH is a wireless technology allowing communication between a mobile device or personal computer over short distances. This enables a hands-free call or data transmission between BLUETOOTH compatible devices.

- *Depending on the BLUETOOTH version, a BLUETOOTH compatible device may not be able to communicate with this unit.*
- *Proper function of this unit with all BLUETOOTH compatible devices is not guaranteed. For handling of the BT compatible device, consult your ALPINE dealer or ALPINE website.*
- *Depending on the surroundings, BLUETOOTH wireless connection may be unstable.*
- *When you place a call, or perform setup operations, be sure to stop your car in a safe place.*
- *Depending on the connected BLUETOOTH compatible device(s), the function may differ. Also refer to the Owner's Manual of the connected device(s).*

Before Using Hands-Free Function

Before using the hands-free phone function, the following settings need to be made.

Set "BT IN" to BT ADAPTER (page 17).

- *Before using a hands-free phone, it must be paired with this unit. Refer to "BLUETOOTH SETUP" (pages 20-21).*

How to connect to a BLUETOOTH compatible device (Pairing)

For details on the control from a BLUETOOTH compatible device, refer to the Owner's Manual of the BLUETOOTH compatible device.

1 Set a BLUETOOTH connection from a BLUETOOTH compatible device.

2 The PIN code ("0000") is displayed on the connected unit.

- *The PIN code is fixed as "0000."*

3 Input the PIN code ("0000") in a BLUETOOTH compatible device.

4 If this unit is successfully connected to a BLUETOOTH compatible device, "CONNECTED" is displayed, and then the unit returns to normal mode.

- *The registration number 5 is deleted when you set ignition from ACC to OFF. If all the 5 positions have been registered, you cannot register the 6th device. To register another device, you need to delete one of the device from position 1 to 5 first.*
- *If a BLUETOOTH compatible device is successfully connected, the next time when the ignition key of the car is turned to on, the unit will automatically connect to the previously connected device. However, the connection may fail. If the auto connection fails, try the connection manually.*
- *Set "Setting the Search Mode" (page 20) to VISI M ON to enable this unit to recognize a mobile phone. For mobile phone passkey (passcode) input operation, refer to the mobile's Owner's Manual.*

BLUETOOTH SETUP

BLUETOOTH Setup Operation

The following steps 1 to 4 are common to the various BLUETOOTH functions. For details, refer to each individual function.

- *While calling, BLUETOOTH Setup operation cannot be performed.*
- *Set "BT IN" to BT ADAPTER, and then perform BLUETOOTH SETUP operation.*

1 Press and hold SOUND/SETUP for at least 2 seconds to activate the SETUP mode.

2 Turn the Rotary encoder to select the desired items and then press ►/II /ENT.

BT IN ↔ PAIRED DEV* ↔ VISIBLE M* ↔ AUTO ANS* ↔ CLEAR DEV* ↔ SEV NAME* ↔ MIC INPUT* ↔ SPEAKER SL* ↔ FW VERSION* ↔ FW UPDATE*

** When "BT IN" is set to BT ADAPTER, the above items are displayed.*

3 Turn the Rotary encoder to change the settings.

4 Press and hold SOUND/SETUP for at least 2 seconds.
The SETUP mode is canceled.

Setting the BLUETOOTH Device

Select one of 5 connected BLUETOOTH compatible devices that you previously registered.

Setting item: PAIRED DEV

Turn the Rotary encoder to select a BLUETOOTH compatible device you want to use (you want to change connection) and then press ►/II /ENT.

- *If the connection is successfully changed, "CONNECTED" is displayed for 2 seconds and the ᛒ indicator lights up, then the display returns to the SETUP screen.*
- *If you input the wrong passcode or communications fail, "FAILED" is displayed.*
- *If you want to connect another BLUETOOTH compatible device, after disconnecting the current BLUETOOTH compatible device, connect the BLUETOOTH compatible device you want to change to. The PIN code is fixed as "0000".*

Setting the Search Mode

You can set whether this unit can be recognized or not from a BLUETOOTH compatible device. Normally set this to VISI M ON.

Setting item: VISIBLE M

VISI M ON: Enable recognition of this unit from the BLUETOOTH compatible device.
VISI M OFF: Disable recognition of this unit from the BLUETOOTH compatible device.

- *Depending on the mobile phone, it may be necessary to input a passcode. For inputting the mobile phone's passcode, refer to the mobile phone's Owner's Manual.*

Setting the Received Calls automatically (Auto Answer)

When a call is received, you can set whether to receive it automatically or not.

Setting item: AUTO ANS

AT ANS ON: When a call is received, it is answered automatically after about 5 seconds.
AT ANS OFF: When a call is received, it is not answered automatically. Press ✆ to receive the call.

- *If the received call setting on the mobile phone is on, the call will be answered automatically even though this setting is set to OFF.*

Deleting a BLUETOOTH Device from the list

You can delete the history of a previously connected BLUETOOTH compatible device.

Setting item: CLEAR DEV

1 Turn the Rotary encoder to select the BLUETOOTH compatible device to be deleted and then press ►/II /ENT.

2 Turn the Rotary encoder to select CLEAR YES if you want to delete and then press ►/II /ENT.

- *Selecting CLEAR NO will cancel the setting.*
- *The registration number 5 is deleted once the ignition key goes from ACC to off.*

Displaying the phone service provider name

Setting item : SEV NAME

The service provider name of the connected BLUETOOTH compatible device will be displayed. If a BLUETOOTH compatible device is not connected, “ID UNSENT” will also be displayed.

- *Depending on the character type some phone service provider name cannot be displayed. “ID UNSENT” will also be displayed.*

Adjusting the volume for the microphone input

You can emphasize or weaken the microphone input volume level.

Setting item : MIC INPUT

Turn the **Rotary encoder** to select the desired volume level (0~7).

- *The setting cannot be adjusted during a phone call. Adjust the setting before placing a call.*

Selecting the output speaker

You can select the connected speaker in car to output the sound signal of telephone.

Setting item : SPEAKER SL

ALL: The sound be output from all of speakers in car.
F-L: The sound only be output from the front left speaker.
F-R: The sound only be output from the front right speaker.
F-LR: The sound be output from the front left and front right speaker.

- *The setting cannot be adjusted during a phone call. Adjust the setting before placing a call.*

Displaying the firmware version

Setting item : FW VERSION

The current firmware version will be displayed.

Updating the firmware

Setting item: FW UPDATE

With this setting, the BLUETOOTH firmware update function can be activated, but other devices and software may be required. For details, consult ALPINE website.

Hands-Free Phone Control

About the Hands-Free Phone

Hands-free calls are possible when using a HSP (Head Set Profile) and HFP (Hands-Free Profile) compatible mobile phone with this unit.

- *Avoid answering a hands-free call in heavy traffic or on narrow or winding streets.*
- *Close the windows while calling to reduce background noise.*
- *If both calling parties are using hands-free devices, or the call is made in a noisy location, difficulty hearing the other person’s voice is normal.*
- *Depending on telephone line conditions or certain mobile devices used, voices may sound unnatural.*
- *When using a microphone, speak as directly as you can into the microphone to pick up the best sound quality.*
- *Certain mobile phone features are dependent on the capabilities and settings of your service provider’s network. Additionally, certain features may not be activated by your service provider, and/or the provider’s network settings may limit the feature’s functionality. Always contact your service provider about feature availability and functionality.*
  All features, functionality, and other product specifications, as well as the information contained in the Owner’s Manual are based upon the latest available information and are believed to be accurate at the time of printing.
  Alpine reserves the right to change or modify any information or specifications without notice or obligation.

Answering a Call

Incoming calls are announced by the received call ring tone and a displayed message (PHONE).

Press ✆.
The call starts.

- *When “Setting the Received Calls automatically (Auto Answer)” (page 20) is set to AT ANS ON, you can receive a call automatically.*
- *While calling, the source sound on the unit is muted. After calling, playback will resume.*

Hanging up the Telephone

Press and hold ⌐ for at least 2 seconds.
The call finishes.

- *While receiving you can also hang up by pressing ✆.*

Redial Function

You can redial the person you have previously called.

After finishing a call “----------” will be displayed, press ✆ within 5 seconds.
The telephone is redialed.

- *If you receive a call from an unknown number, you cannot use the redial function to call back.*

Calling

Call History is recorded for the last dialed/received/missed calls. There are various ways of making calls based on the "Calling." The following steps 1 to 5 are common to the various ways of making these calls. For details, refer to each individual category for making calls.

1 **Press ✆.**
The outgoing method list is displayed.

2 **Turn the Rotary encoder to select the outgoing mode.**

Setting items : DIALED / RECEIVED / MISSED / PHONE BOOK

DIALED: Dialed history
RECEIVED: Received history
MISSED: Missed incoming history
PHONE BOOK: Mobile phonebook

3 **Press ▶/❙❙ /ENT.**
The outgoing mode is activated, and each mode list is displayed.

- *It may take some time for the list to be displayed, and also directly after connection, the list may not be brought up to date.*

4 **Turn the Rotary encoder to select a name or a telephone number from the list.**

- *You can use Alphabet skip function to search a name or number from Phone Book. For details, refer to "Phone Book Alphabet Skip" (page 22).*

5 **Press ▶/❙❙ /ENT.**
The selected telephone will be called.

If one name has several numbers registered in the telephone book, press ▶/❙❙ /ENT after selecting the name*, then turn the Rotary encoder to choose the desired number and press ▶/❙❙ /ENT, the telephone will be called. Press and hold ▶/❙❙ /ENT for at least 2 seconds after selecting the name, the default number of the name will be called. Depending on the connected mobile phone, this function may not be performed.

* *If the name cannot be recognized, default number will be displayed.*

- *The names registered in the telephone book are displayed. If the name is not registered, a number is displayed. If both name and number cannot be displayed, "ID UNSENT" will be displayed.*
- *If you place a call directly from the paired mobile phone, the phone number is not displayed, you cannot redial from the unit in this case.*

Redialing a Number In Outgoing History

Previously dialed telephone numbers are stored in dialed calls history. You can redial a number by searching from dialed calls history.

Setting item: DIALED

Dialing a Number In Incoming History

Telephone numbers from received calls are stored in the Received List. You can redial these numbers by searching here.

Setting item: RECEIVED

Dialing a Number In Incoming Missed Call History

Telephone numbers for received calls that are missed, are stored in the Missed List. You can redial these numbers by searching here.

Setting item: MISSED

Dialing a Number In The Phone Book

Up to 1,000 telephone numbers are downloadable from a mobile phone. Dial a call by selecting a person from the phone book list.

Setting item: PHONE BOOK

- *If a name cannot be obtained via the phonebook, "----------" is displayed.*
- *The order of the list display depends on the design of the mobile phone.*
- *If the call history or phonebook of the mobile phone is added or deleted while it is connected to the unit, the list displayed on the unit may not be brought up to date. If it is not updated, you cannot correctly place a call.*

Phone Book Alphabet Skip

The initial skip function is skipped to the next number, symbol or letter such as from A to B, B to C.

You can skip in reverse order such as B to A by pressing **1 ◀ (✆ ABC)**.

1 **During search mode, press 1 ◀ or ▶ 2 (✆ ABC) to perform the Alphabet Skip Function.**
A list is skipped to the next number, symbol or letter.

Voice Dial Operation

You can call the telephone by performing voice operation.

1 **Press and hold ✆/VOICE DIAL for at least 2 seconds.**
The speak mode is activated, and "SPEAK" is displayed.

2 **Say the telephone number, name you want to call into the microphone.**

- *You can perform this operation only when a voice dial compatible mobile phone is connected. If the mobile phone is not compatible with the voice dial, "NO SUPPORT" is displayed for 2 seconds.*
- *The Voice Dial function performance depends on the recognition range of the mobile phone and mounting location of the microphone. Note when the microphone is mounted.*
- *Voice dial operation depends on the function of the mobile phone. For details, refer to the Owner's Manual of the mobile phone.*
- *If a called person that you say is not found, "NO CALL" is displayed for 2 seconds.*
- *If you place a call via voice dial, you cannot display a phone number or name.*

Adjusting the volume when receiving a Call

While calling, you can adjust the volume.

Turn the Rotary encoder to adjust the volume.

- *You may need to increase volume from your regular audio listening source level. However, increasing the volume excessively may result in feedback. If feedback is noticed as feedback is directly related to the volume, turn down the volume as low as acceptable to eliminate it. Positioning the microphone in a direction away from the main car speakers (e.g. clipped on sun visor) may also reduce feedback at high volume.*

Call Switching Operation

While making a call, this function allows you to initiate the transfer of the audio between the mobile phone and the speakers in the car.

While calling, press and hold ►/II /ENT for at least 2 seconds to switch the call sound between the unit and mobile phone.

- *Depending on the mobile phone, this operation may not be performed.*

USB memory (Optional)



Playing MP3/WMA/AAC Files with the USB memory (Optional)

If you connect a USB memory containing MP3/WMA/AAC, the following table shows which type of files can be played on which models.

	MP3	WMA	AAC
CDE-126BT	○	○	○
CDE-125BT	○		

1 Press SOURCE/⏻ to switch to the USB AUDIO mode.

The mode will change every time the button is pressed.

TUNER → DISC → USB AUDIO → iPod*[1]/AUX+*[2] → AUX*[3] → TUNER

*[1] *Displayed only when the iPod/iPhone is connected and AUX+ SETUP is set to OFF, refer to "Setting the AUX+ SETUP Mode" (page 19).*

*[2] *Displayed only when the AUX+ SETUP is set to ON, refer to "Setting the AUX+ SETUP Mode" (page 19).*

*[3] *Refer to "Using the Front AUX Input Terminal" (page 16).*

2 To pause playback, press ►/II /ENT.

Pressing ►/II /ENT again will resume the playback.

- *The root folder is displayed as "ROOT" in the Folder Name Search mode.*
- *When a search is made in the USB mode, any song being played back will be stopped.*
- *This unit plays back files on a USB memory device with the same controls and modes as playback of CDs containing MP3/WMA/AAC. For details, refer to "CD/MP3/WMA/AAC" on pages 10 to 13.*
- *Before disconnecting USB memory, be sure to change to another source or set to pause.*
- *The playback time may not be correctly displayed when a VBR (Variable Bit Rate) recorded file is played back.*

USB Memory Connection (Optional)

Connect USB memory

1 **Open the cover of the USB connection terminal.**

2 **Connect the USB memory directly to the USB connection terminal, or via the USB cable.**



Remove USB memory

1 **Carefully, pull out the USB memory from the USB cable or the USB connection terminal.**

2 **Close the cover of the USB connection terminal.**

- *Change to a source other than the USB memory mode, then remove the USB memory. If the USB memory is removed in the USB memory mode, data may be damaged.*
- *When removing USB memory, pull it out straight.*
- *If sound is not output or USB memory is not recognized even when USB memory is connected, remove USB memory once, then connect it again.*
- *Route the USB cable away from other cables, etc.*
- *After removing the USB memory, close the cover of the USB connection terminal to prevent dust or foreign objects from entering and causing a malfunction.*

About MP3/WMA/AAC File of USB Memory

Playing back MP3/WMA/AAC

MP3/WMA/AAC files are prepared, then stored to a USB memory. This unit can recognize at most 100 folders (including root folder) and 100 files per folder stored in USB memory. Playback may not be performed if a USB memory exceeds the limitations described above.
Do not make a file's playback time more than 1 hour.

Media supported

This device can play back USB memory media.

Corresponding File Systems

This device supports FAT 16/32 for USB memory device.

iPod/iPhone (Optional)



An iPod/iPhone can be connected to this unit by using the proprietary ALPINE FULL SPEED Connection Cable (KCE-433iV) (Supplied, CDE-126BT only). When this unit is connected by using the cable, the controls on the iPod are not functional.

- *Set AUX+ SETUP to OFF when an iPod/iPhone is connected (refer to "Setting the AUX+ SETUP Mode" on page 19).*
- *If you connect an iPhone to this unit, it can be used as an iPod. If you use iPhone as a hands-free phone, use the unit in which the BLUETOOTH function is built.*
- *Internet and telephone functions of iPod touch or iPhone, etc., can also be used when connecting to the unit. However, using these functions will stop or pause the playing songs, at this time do not operate the unit to avoid a malfunction.*
- *Do not leave an iPod/iPhone in a car, as its mechanism is sensitive to high temperature and humidity conditions, and damage may result.*

iPod/iPhone models usable with this unit

- Confirmed devices regarding Made for iPod. Correct function of earlier versions cannot be guaranteed.

  iPod touch (Late 2009): Ver.3.1.3
  iPod nano (5th generation): Ver.1.0.2
  iPod classic (Late 2009): Ver.2.0.4
  iPod touch (2nd generation): Ver.3.1.3
  iPod nano (4th generation): Ver.1.0.4
  iPod classic (120GB): Ver.2.0.1
  iPod touch (1st generation): Ver.3.1.3
  iPod nano (3rd generation): Ver.1.1.3
  iPod classic (80GB, 160GB): Ver.1.1.2
  iPod nano (2nd generation): Ver.1.1.3
  iPod with video: Ver.1.3
  iPod nano (1st generation): Ver.1.3.1

- Confirmed devices regarding Made for iPhone. Correct function of earlier versions cannot be guaranteed.

  iPhone 3GS: Ver.3.1.3
  iPhone 3G: Ver.3.1.3
  iPhone: Ver.3.1.3

- For clarity in identifying your model of iPod, please see Apple's own document "Identifying iPod models" at http://support.apple.com/kb/HT1353.
- This unit does not support video playback from iPod/iPhone, even using a video-compatible cable.

Playback

1 Press SOURCE/⏻ to switch to the iPod mode.

TUNER → DISC → USB AUDIO → iPod*1/AUX+*2 → AUX*3 → TUNER

*1 *Displayed only when the iPod/iPhone is connected and AUX+ SETUP is set to OFF, refer to "Setting the AUX+ SETUP Mode" (page 19).*

*2 *Displayed only when the AUX+ SETUP is set to ON, refer to "Setting the AUX+ SETUP Mode" (page 19).*

*3 *Refer to "Using the Front AUX Input Terminal" (page 16).*

2 Press ⏮ or ⏭ to select the desired song.

Return to the beginning of the current song:
Press ⏮.

Fast backward through current song:
Press and hold ⏮.

Advance to the beginning of the next song:
Press ⏭.

Fast forward through current song:
Press and hold ⏭.

3 To pause playback, press ▶/❚❚ /ENT.
Pressing ▶/❚❚ /ENT again will resume playback.

- *A song playing on the iPod/iPhone while it is connected to this unit will continue to play from where it was paused after disconnection.*
- *If you listen to an episode from a selected podcast or audiobook, the episode can be changed by pressing **1** ◀ or ▶ **2**.*
- *An episode may have several chapters, the chapter can be changed by pressing ⏮ or ⏭.*

Searching for a desired Song

An iPod/iPhone can contain hundreds of songs. By using file tag information and keeping these songs organized in playlists, this unit's search functions will ease song searches.
Each music category has its own individual hierarchy. Use the Playlist/Artist/Album/Song/Podcast/Genre/Composer/Audiobook search mode to narrow searches based on the table below.

Hierarchy 1	Hierarchy 2	Hierarchy 3	Hierarchy 4
Playlist	Song	—	—
Artist*	Album*	Song	—
Album*	Song	—	—
Song	—	—	—
Podcast	Episode	—	—
Genre*	Artist*	Album*	Song
Composer*	Album*	Song	—
Audiobook	—	—	—

For example: Searching by Artist name
The following example explains how an ARTIST search is performed. Another search mode can be used for the same operation, although the hierarchy differs.

1 Press 🔍/ESC to activate the search selection mode.
The "🔍" indicator lights up.

2 Turn the Rotary encoder to select the ARTIST search mode, and then press ▶/❚❚ /ENT.

PLAYLIST ↔ ARTIST ↔ ALBUM ↔ SONG ↔ PODCAST ↔ GENRE ↔ COMPOSER ↔ AUDIOBOOK ↔ PLAYLIST

3 Turn the Rotary encoder to select the desired Artist, and then press ▶/❚❚ /ENT.

4 Turn the Rotary encoder to select the desired Album, and then press ▶/❚❚ /ENT.

5 Turn the Rotary encoder to select the desired Song, and then press ▶/❚❚ /ENT.

- *After pressing and holding ▶/❚❚ /ENT for at least 2 seconds while in each hierarchy (except SONG and AUDIOBOOK hierarchy), all songs of the selected hierarchy are played back.*
- *After selecting [ALL] in the search mode with"*", press and hold ▶/❚❚ /ENT for at least 2 seconds to play back all songs in the iPod/iPhone or selected search mode.*
- *While in the search mode, if you press and hold 🔍/ESC for 2 seconds, or no operation is performed for 10 seconds, the search mode is canceled.*
- *In the search mode, pressing ⮌/MUTE will return to the previous mode.*
- *When search is made during M.I.X. play, the M.I.X. play mode will be canceled.*
- *"NO SONG" will be displayed if there are no songs in the selected playlist in the PLAYLIST search mode.*
- *"NO PODCAST" will be displayed if there is no podcast data in the iPod/iPhone in the PODCAST search mode.*
- *"NOAUDIOBOK" will be displayed if there is no audiobook data in the iPod/iPhone in the AUDIOBOOK search mode.*
- *If "iPod name" stored in the iPod/iPhone is selected in the desired Playlist search mode, and ▶/❚❚ /ENT is pressed, you can search for all songs in the iPod/iPhone. Also, if you press and hold ▶/❚❚ /ENT for at least 2 seconds, all songs in the iPod/iPhone are played back.*
- *Depending on the iPod/iPhone, podcast search is not supported.*
- *If any one of the **preset buttons (1 through 6)** is pressed in the search mode, a search can be made quickly by skipping to the specified location. For details, refer to "Direct Search Function" on page 26.*

Quick Search

You can search a song from all songs in the iPod/iPhone without selecting an album, artist, etc.

1 Press and hold 🔍/ESC for at least 2 seconds to activate the Quick Search mode.
The "🔍" indicator lights up.

2 Turn the Rotary encoder to select a desired song.
The selected song is played back immediately.

- *Press and hold 🔍/ESC for at least 2 seconds in the search mode to cancel. Or, the search mode is canceled if no operation is performed for 10 seconds.*
- *If many songs are in the iPod/iPhone, it takes time to search for songs.*
- *If any one of the **preset buttons (1 through 6)** is pressed in the search mode, a search can be made quickly by skipping to the specified location. For details, refer to "Direct Search Function" on page 26.*
- *This function is inactive during repeat (🔁) playback.*

Direct Search Function

The unit's direct search function can be used to search for an album, song, etc., more efficiently. In PLAYLIST/ARTIST/ALBUM/SONG/PODCAST/GENRE/COMPOSER/AUDIOBOOK mode, you can quickly target any song.

In the search mode, press any one of the preset buttons (1 through 6) to quickly skip over a designated percent of your song content.

Song search example:
If there are 100 songs in your iPod/iPhone, they are divided into 6 groups using percentages (shown below). These groups are assigned to the preset buttons (1 through 6).

Example 1:
Suppose the song you are searching for is located at around the middle (50%) of your library: press button 4 to jump to the 50th song and turn the Rotary encoder to find the desired song.

Example 2:
Suppose the song you are searching for is located near the end (83%) of your library: press button 6 to jump to the 83rd song and turn the Rotary encoder to find the desired song.

	All 100 songs (100%)					
	0%	17%	33%	50%	67%	83%
Preset buttons	1	2	3	4	5	6
Songs	First song	17th song	33rd song	50th song	67th song	83rd song

Select Playlist/Artist/Album/Genre/Composer

Playlist/Artist/Album/Genre/Composer can be easily changed.
For example, if you listen to a song from a selected album, the album can be changed.

Press 1 ◀ or ▶ 2 to select the desired Playlist/Artist/Album/Genre/Composer.

- *If the song search mode was used to select a song, this function is inactive.*
- *If an album is selected during an artist search, other albums by that artist are searchable.*
- *This function is inactive during shuffle (🔀) playback.*

Random Play Shuffle (M.I.X.)

The Shuffle function of the iPod/iPhone is displayed as 🔀 on this unit.

Shuffle Albums:
The songs on each album are played back in proper order. Upon completion of all the songs on the album, the next album is selected randomly. This continues until all albums have been played.

Shuffle Songs:
Song shuffle randomly plays back songs within a selected category (playlist, album, etc.). The songs within the category are played just once until all songs have been played.

1 Press 5 🔀.
The songs are played back in random sequence.
📁🔀 → 🔀 → (off) → 📁🔀
(Shuffle Albums) (Shuffle Songs)

2 To cancel M.I.X. play, select (off) with the above procedure.

- *If a song is selected in the album search mode before selecting M.I.X. play, the songs will not play back randomly even when Shuffle Albums is selected.*

Shuffle ALL:
Shuffle ALL plays all songs in the iPod/iPhone randomly. Any one song does not play back again until all songs have been played back.

1 Press 6.
The songs are played back in random sequence.
🔀 → (off) → 🔀
(Shuffle ALL)

2 To cancel M.I.X. play, select (off) with the above procedure.

- *If Shuffle ALL is selected, the selected songs being played back in the search mode are canceled.*

Repeat Play

Only Repeat One is available for the iPod/iPhone.

Repeat One:
A single song is repeatedly played back.

1 **Press 4.**
The song is played back repeatedly.

(off) → (Repeat One)

2 **To cancel repeat play, select (off) with the above procedure.**

- *During repeat playback, no other songs are selectable by pressing ◀◀ or ▶▶.*

Displaying the Text

You can display the tag information of a song in the iPod/iPhone.

Press VIEW.
Each press changes the display.

- *When the TEXT SCR is set to SCR MANU, press and hold **VIEW** for at least 2 seconds, the current text will be scrolled one time.*

  TRACK NO./ELAPSED TIME → TRACK NO./CLOCK → ARTIST NAME* → ALBUM NAME* → SONG TITLE* → TRACK NO./ELAPSED TIME

* *TAG information*
"ARTIST"/"ALBUM"/"SONG" is displayed if there is no tag information.

- *Only alphanumeric characters (ASCII) can be displayed.*
- *If the artist, album or song name, created in iTunes, has too many characters, songs may not be played back when connected to the adapter. Therefore, a maximum of 250 characters is recommended. The maximum number of characters for the head unit is 64 (64 bytes).*
- *Some characters may not be correctly displayed.*
- *"NO SUPPORT" is displayed if text information is not supported by the unit.*

Information

In Case of Difficulty

If you encounter a problem, please turn the power off, then on again. If the unit is still not functioning normally, please review the items in the following checklist. This guide will help you isolate the problem if the unit is at fault. Otherwise, make sure the rest of your system is properly connected or consult your authorized Alpine dealer.

Basic

No function or display.
- Vehicle's ignition is off.
  - If connected following instructions, the unit will not operate with the vehicle's ignition off.
- Improper power lead (Red) and battery lead (Yellow) connections.
  - Check power lead and battery lead connections.
- Blown fuse.
  - Check the fuse of the unit; replace with the proper value if necessary.
- Internal micro-computer malfunctioned due to interference noise etc.
  - Press the RESET switch with a ballpoint pen or other pointed article.

Radio

Unable to receive stations.
- No antenna or open connection in cable.
  - Make sure the antenna is properly connected; replace the antenna or cable if necessary.

Unable to tune stations in the seek mode.
- You are in a weak signal area.
  - Make sure the tuner is in the DX mode.
- If the area you are in is a primary signal area, the antenna may not be grounded and connected properly.
  - Check your antenna connections; make sure the antenna is properly grounded at its mounting location.
- The antenna may not be the proper length.
  - Make sure the antenna is fully extended; if broken, replace the antenna with a new one.

Broadcast is noisy.
- The antenna is not the proper length.
  - Extend the antenna fully; replace it if it is broken.
- The antenna is poorly grounded.
  - Make sure the antenna is grounded properly at its mounting location.

CD

CD Player not functioning.

- Out of operating temperature range +50°C (+120°F) for CD.
  - Allow the vehicle's interior (or trunk) temperature to cool.

CD playback sound is wavering.

- Moisture condensation in the CD Module.
  - Allow enough time for the condensation to evaporate (about 1 hour).

CD insertion not possible.

- A CD is already in the CD player.
  - Eject the CD and remove it.
- The CD is being improperly inserted.
  - Make sure the CD is being inserted following instructions in the CD Player Operation section.

Unable to fast forward or backward the CD.

- The CD has been damaged.
  - Eject the CD and discard it; using a damaged CD in your unit can cause damage to the mechanism.

CD playback sound skips due to vibration.

- Improper mounting of the unit.
  - Securely re-mount the unit.
- The disc is very dirty.
  - Clean the disc.
- The disc has scratches.
  - Change the disc.
- The pick-up lens is dirty.
  - Do not use a commercially available lens cleaner disc. Consult your nearest Alpine dealer.

CD playback sound skips without vibration.

- The disc is dirty or scratched.
  - Clean the disc; damaged disc should be replaced.

Error displays (built-in CD player only).

- Mechanical error.
  - Press ⏏. After the error indication disappears, insert the disc again. If the above-mentioned solution does not solve the problem, consult your nearest Alpine dealer.

CD-R/CD-RW playback not possible.

- Close session (finalization) has not been performed.
  - Perform finalization and attempt playback again.

MP3/WMA/AAC

MP3, WMA or AAC is not played back.

- Writing error occurred. The MP3/WMA/AAC format is not compatible.
  - Make sure the MP3/WMA/AAC has been written in a supported format. Refer to "About MP3/WMA/AAC" (pages 12-13), then rewrite in the format supported by this device.

Audio

The sound is not output from the speakers.

- Unit has no output signal of the internal amplifier.
  - POWER IC is switched to "POW ON" (page 18).

iPod

iPod does not play and no sound is output.

- The iPod has not been recognized.
  - Reset this unit and the iPod. Refer to "Initial System Start-Up" (page 8). To reset the iPod, refer to the Owner's Manual of the iPod.

Indication for CD Player

NO DISC

- No CD is inserted.
  - Insert a CD.
- Although a disc is inserted, "NO DISC" is displayed and the unit does not start to play or eject the disc.
  - Remove the disc by following these steps:
    Press the ⏏ button again for at least 2 seconds.
    If the disc still does not eject, consult your Alpine dealer.

ERROR

- Mechanism error.
  1) Press the ⏏ button and eject the CD.
     If not ejecting, consult your Alpine dealer.
  2) When the error indication remains after ejecting, press the ⏏ button again.
     If the error indication still does not turn off after pressing the ⏏ button for a few times, consult your Alpine dealer.
- *When "ERROR" is displayed:*
  If the disc cannot be ejected by pressing ⏏, press the RESET switch (refer to page 8) and press ⏏ again.
  If the disc still cannot be ejected, consult your Alpine dealer.

PROTECT

- A copy-protected WMA file was played back.
  - You can only play back non-copy-protected files.

UNSUPORTED

- A sampling rate/bit rate not supported by the unit is used.
  - Use a sampling rate/bit rate that is supported by the unit.

Indication for USB memory

ERROR

- Abnormal current is run to the USB connector device (an error message may be displayed if the USB device that is not compatible with the unit is connected).
  USB memory is a malfunction or it is shorted.
  - Connect another USB memory.

UNIT ERROR

- A USB device that is not supported by the unit is connected.
  - Connect a USB device that is supported by the unit.

NO DEVICE

- A USB memory is not connected.
  - Make sure the USB memory device is correctly connected and the cable is not excessively bent.

NO FILE

- No song (file) is stored in the USB memory.
  - Connect the USB memory device after storing songs (files).

UNSUPORTED

- A sampling rate/bit rate not supported by the unit is used.
  - Use a sampling rate/bit rate that is supported by the unit.

PROTECT

- A copy-protected WMA file was played back.
  - You can only play back non-copy-protected files.

NO SUPPORT

- Text information that is not recognizable by the unit has been input.
  - Use a USB memory device with input text information that is supported by the unit.

Indication for iPod Mode

NO IPOD

- The iPod/iPhone is not connected.
  - Make sure the iPod/iPhone is correctly connected (refer to “Connections”).
    Make sure the cable is not bent excessively.

NO SONG

- There are no songs in the iPod/iPhone.
  - Download songs to the iPod/iPhone and connect to this unit.

ERROR-01

- Communication error.
  - Turn the ignition key off, and then set to ON again.
  - Reset the iPod.
  - Check the display by reconnecting between the iPod/iPhone and this unit, using the iPod/iPhone cable.

ERROR-02

- Caused by the iPod/iPhone Software Version not being compatible with this unit.
  - Update the iPod/iPhone Software Version to be compatible with this unit.

ERROR-03

- The iPod/iPhone is not verified.
  - Reset the iPod.
  - Try another iPod/iPhone, if available.

ERROR-04

- Power surge error.
  Excessive voltage/current is supplied to the iPod/iPhone.
  - Try another iPod/iPhone, if available.

BLUETOOTH mode

NO UNIT

- The BLUETOOTH device is not connected.
  - Connect the BLUETOOTH device.

Indication for all Modes

DC ERROR

- Malfunction occurred as a result of the speaker cable shorting on the car chassis.
  - Route the cable correctly, and set POWER IC to POW ON (page 18).
    If the above solution does not work, consult your nearest dealer.

Specifications

FM TUNER SECTION

Tuning Range	87.7-107.9 MHz
Mono Usable Sensitivity	9.3 dBf (0.8 µV/75 ohms)
50 dB Quieting Sensitivity	13.5 dBf (1.3 µV/75 ohms)
Alternate Channel Selectivity	80 dB
Signal-to-Noise Ratio	65 dB
Stereo Separation	35 dB
Capture Ratio	2.0 dB

AM TUNER SECTION

Tuning Range	530-1,710 kHz
Sensitivity (IEC Standard)	22.5 µV/27 dB

CD PLAYER SECTION

Frequency Response	5-20,000 Hz (±1 dB)
Wow & Flutter (% WRMS)	Below measurable limits
Total Harmonic Distortion	0.008% (at 1 kHz)
Dynamic Range	95 dB (at 1 kHz)
Signal-to-Noise Ratio	105 dB
Channel Separation	85 dB (at 1 kHz)

PICKUP

Wave length	795 nm
Laser power	CLASS I

USB SECTION

USB requirements	USB 1.1/2.0
Max. Power Consumption	500 mA
USB Class	Mass Storage
File System	FAT 16/32
MP3 Decoding	MPEG-1/2 AUDIO Layer-3
WMA Decoding	Windows Media™ Audio
AAC Decoding	AAC-LC format ".m4a" file
Number of Channels	2-Channel (Stereo)
Frequency Response*	5-20,000 Hz (±1 dB)
Total Harmonic Distortion	0.008% (at 1 kHz)
Dynamic Range	95 dB (at 1 kHz)
Signal-to-Noise Ratio	105 dB
Channel Separation	85 dB (at 1 kHz)

* Frequency response may differ depending on the encoder software/bit rate.

BLUETOOTH SECTION

BLUETOOTH Specification	BLUETOOTH V 2.0
Output Power	+4 dBm Max. (Power class 2)
HFP	(Hands-Free Profile)
HSP	(Head Set Profile)

GENERAL

Power Requirement	14.4 V DC (11-16 V allowable)
Power Output	18 W RMS × 4*

* Primary amplifier ratings per CEA-2006 Standard

- Power output: measured at 4 Ohms and ≤ 1% THD+N
- S/N: 80 dBA (reference: 1 W into 4 Ohms)

Maximum Pre-Output Voltage	2 V/10 k ohms
Bass	±14 dB at 100 Hz
Treble	±14 dB at 10 kHz
Weight	1.5 kg (3 lbs. 4 oz)

CHASSIS SIZE

Width	178 mm (7")
Height	50 mm (2")
Depth	161 mm (6-3/8")

NOSEPIECE SIZE

Width	170 mm (6-3/4")
Height	46 mm (1-13/16")
Depth	25 mm (1")

- *Due to continuous product improvement, specifications and design are subject to change without notice.*

Installation and Connections

Before installing or connecting the unit, please read the following and pages 5 to 7 of this manual thoroughly for proper use.

⚠ Warning

MAKE THE CORRECT CONNECTIONS.

Failure to make the proper connections may result in fire or product damage.

USE ONLY IN CARS WITH A 12 VOLT NEGATIVE GROUND.

(Check with your dealer if you are not sure.) Failure to do so may result in fire, etc.

BEFORE WIRING, DISCONNECT THE CABLE FROM THE NEGATIVE BATTERY TERMINAL.

Failure to do so may result in electric shock or injury due to electrical shorts.

DO NOT ALLOW CABLES TO BECOME ENTANGLED IN SURROUNDING OBJECTS.

Arrange wiring and cables in compliance with the manual to prevent obstructions when driving. Cables or wiring that obstruct or hang up on places such as the steering wheel, gear lever, brake pedals, etc. can be extremely hazardous.

DO NOT SPLICE INTO ELECTRICAL CABLES.

Never cut away cable insulation to supply power to other equipment. Doing so will exceed the current carrying capacity of the wire and result in fire or electric shock.

DO NOT DAMAGE PIPE OR WIRING WHEN DRILLING HOLES.

When drilling holes in the chassis for installation, take precautions so as not to contact, damage or obstruct pipes, fuel lines, tanks or electrical wiring. Failure to take such precautions may result in fire.

DO NOT USE BOLTS OR NUTS IN THE BRAKE OR STEERING SYSTEMS TO MAKE GROUND CONNECTIONS.

Bolts or nuts used for the brake or steering systems (or any other safety-related system), or tanks should NEVER be used for installations or ground connections. Using such parts could disable control of the vehicle and cause fire etc.

KEEP SMALL OBJECTS SUCH AS BATTERIES OUT OF THE REACH OF CHILDREN.

Swallowing them may result in serious injury. If swallowed, consult a physician immediately.

DO NOT INSTALL IN LOCATIONS WHICH MIGHT HINDER VEHICLE OPERATION, SUCH AS THE STEERING WHEEL OR GEARSHIFT.

Doing so may obstruct forward vision or hamper movement etc. and results in serious accident.

⚠ Caution

HAVE THE WIRING AND INSTALLATION DONE BY EXPERTS.

The wiring and installation of this unit requires special technical skill and experience. To ensure safety, always contact the dealer where you purchased this product to have the work done.

USE SPECIFIED ACCESSORY PARTS AND INSTALL THEM SECURELY.

Be sure to use only the specified accessory parts. Use of other than designated parts may damage this unit internally or may not securely install the unit in place. This may cause parts to become loose resulting in hazards or product failure.

ARRANGE THE WIRING SO IT IS NOT CRIMPED OR PINCHED BY A SHARP METAL EDGE.

Route the cables and wiring away from moving parts (like the seat rails) or sharp or pointed edges. This will prevent crimping and damage to the wiring. If wiring passes through a hole in metal, use a rubber grommet to prevent the wire's insulation from being cut by the metal edge of the hole.

DO NOT INSTALL IN LOCATIONS WITH HIGH MOISTURE OR DUST.

Avoid installing the unit in locations with high incidence of moisture or dust. Moisture or dust that penetrates into this unit may result in product failure.

Precautions

- Be sure to disconnect the cable from the (–) battery post before installing your CDE-126BT/CDE-125BT. This will reduce any chance of damage to the unit in case of a short-circuit.
- Be sure to connect the color coded leads according to the diagram. Incorrect connections may cause the unit to malfunction or damage to the vehicle's electrical system.
- When making connections to the vehicle's electrical system, be aware of the factory installed components (e.g. on-board computer). Do not tap into these leads to provide power for this unit. When connecting the CDE-126BT/CDE-125BT to the fuse box, make sure the fuse for the intended circuit of the CDE-126BT/CDE-125BT has the appropriate amperage. Failure to do so may result in damage to the unit and/or the vehicle. When in doubt, consult your Alpine dealer.
- The CDE-126BT/CDE-125BT uses female RCA-type jacks for connection to other units (e.g. amplifier) having RCA connectors. You may need an adapter to connect other units. If so, please contact your authorized Alpine dealer for assistance.
- Be sure to connect the speaker (–) leads to the speaker (–) terminal. Never connect left and right channel speaker cables to each other or to the vehicle body.

IMPORTANT

Please record the serial number of your unit in the space provided below and keep it as a permanent record. The serial number or the engraved serial number is located on the bottom of the unit.

SERIAL NUMBER: _____

INSTALLATION DATE: _____

INSTALLATION TECHNICIAN: _____

PLACE OF PURCHASE: _____

Installation



Caution

When you install this unit in your car, do not remove the detachable front panel.
If the detachable front panel is removed during installation, you might press too hard and warp the metal plate that holds it in place.

- *The main unit must be mounted within 35 degrees of the horizontal plane, back to front.*



1



* *If the installed mounting sleeve is loose in the dashboard, the pressure plates may be bent slightly to remedy the problem.*

Remove the mounting sleeve from the main unit (see "Removal" on page 32).

2



Reinforce the head unit with the metal mounting strap (not supplied). Secure the ground lead of the unit to a clean metal spot using a screw (*1) already attached to the vehicle's chassis.

- *For the screw marked "*2", use an appropriate screw for the chosen mounting location.*

Connect each input lead coming from an amplifier to the corresponding output lead coming from the left rear of the CDE-126BT/CDE-125BT. Connect all other leads of the CDE-126BT/CDE-125BT according to details described in the CONNECTIONS section.

3 **Slide the CDE-126BT/CDE-125BT into the dashboard until it clicks. This ensures that the unit is properly locked and will not accidentally come out from the dashboard. Install the detachable front panel.**

Removal

1. Remove the detachable front panel.
2. Insert the bracket keys into the unit, along the guides on either side. The unit can now be removed from the mounting sleeve.



3. Pull the unit out, keeping it unlocked as you do so.

<JAPANESE CAR>





*Secure the ground lead of the unit to a clean metal spot using a screw (*3) already attached to the vehicle's chassis.*

Mounting the Microphone

For the sake of safety, mount the microphone in the following location.

- In a stable and secure location.
- In a location that does not inhibit safely driving the vehicle.
- Mount the microphone in a location where the driver's voice can easily be picked up.

Choose a location for the microphone that can easily pick up the driver's voice. Requiring the driver to move towards the microphone for audibility causes a distraction that could be dangerous.

Connections



*1 *When Subwoofer is OFF: Output is for Rear speakers. When Subwoofer is ON: Output is for Subwoofer.*

*2 *When Subwoofer is OFF: Output is for Front speakers. When Subwoofer is ON: Output is for Subwoofer.*

For details on how to set the Subwoofer to ON/OFF, see "Subwoofer On and Off" on page 17.

① **Antenna Receptacle**

② **Power Antenna Lead (Blue)**
Connect this lead to the +B terminal of your power antenna, if applicable.

- *This lead should be used only for controlling the vehicle's power antenna. Do not use this lead to turn on an amplifier or a signal processor, etc.*

③ **Remote Turn-On Lead (Blue/White)**
Connect this lead to the remote turn-on lead of your amplifier or signal processor.

④ **Audio Interrupt In Lead (Pink/Black)**
Not used for this unit.

⑤ **Illumination Lead (Orange)**
This lead may be connected to the vehicle's instrument cluster illumination lead. This will allow the backlighting of this unit to dim whenever the vehicle's lights are turned on.

⑥ **Switched Power Lead (Ignition) (Red)**
Connect this lead to an open terminal on the vehicle's fuse box or another unused power source which provides (+)12V only when the ignition is turned on or in the accessory position.

⑦ **Battery Lead (Yellow)**
Connect this lead to the positive (+) post of the vehicle's battery.

⑧ **Ground Lead (Black)**
Connect this lead to a good chassis ground on the vehicle. Make sure the connection is made to bare metal and is securely fastened using the sheet metal screw provided.

⑨ **Power Supply Connector**

⑩ **Right Front (+) Speaker Output Lead (Gray)**

⑪ **Right Front (–) Speaker Output Lead (Gray/Black)**

⑫ **Right Rear (–) Speaker Output Lead (Violet/Black)**

⑬ **Right Rear (+) Speaker Output Lead (Violet)**

⑭ **Left Rear (+) Speaker Output Lead (Green)**

⑮ **Left Rear (–) Speaker Output Lead (Green/Black)**

⑯ **Left Front (–) Speaker Output Lead (White/Black)**

⑰ **Left Front (+) Speaker Output Lead (White)**

⑱ **Fuse Holder (10A)**

⑲ **Front Output RCA Connectors (CDE-126BT only)**
RED is right and WHITE is left.

⑳ **Rear/Subwoofer Output RCA Connectors (CDE-126BT only)**

⑳ **Front/Subwoofer Output RCA Connectors (CDE-125BT only)**
RED is right and WHITE is left.

㉑ **MIC Input Connector**
To Microphone.

㉒ **RCA Extension Cable (sold separately)**

㉓ **Full Speed Connector**
Control iPod/iPhone signals.
Connect this to an iPod/iPhone by using FULL SPEED Connection Cable (KCE-433iV) (Supplied, CDE-126BT only) or to an external device (such as a portable player) by using conversion cable (KCE-237B) for building up the AUX IN (sold separately).

- *Refer to "Setting the AUX+ SETUP Mode" (page 19).*

AUX+ ON : When the external device is connected.
AUX+ OFF : When an iPod/iPhone is connected.

㉔ **FULL SPEED Connection Cable (KCE-433iV) (Supplied, CDE-126BT only)**

㉕ **Front AUX Input Terminal**
This terminal allows for input of audio from an external device (such as a portable player), using a commercially-available converter cable.

㉖ **USB Connection Terminal**
Connect USB memory (sold separately)

To prevent external noise from entering the audio system.

- Locate the unit and route the leads at least 10 cm away from the car harness.
- Keep the battery power leads as far away from other leads as possible.
- Connect the ground lead securely to a bare metal spot (remove any paint, dirt or grease if necessary) of the car chassis.
- If you add an optional noise suppressor, connect it as far away from the unit as possible. Your Alpine dealer carries various noise suppressors, contact them for further information.
- Your Alpine dealer knows best about noise prevention measures so consult your dealer for further information.

LIMITED WARRANTY

ALPINE ELECTRONICS OF AMERICA, INC. AND ALPINE OF CANADA INC. (“Alpine”), are dedicated to quality craftsmanship and are pleased to offer this Warranty. We suggest that you read it thoroughly. Should you have any questions, please contact your Dealer or contact Alpine at one of the telephone numbers listed below.

● PRODUCTS COVERED:

This Warranty covers Car Audio Products and Related Accessories (“the product”). Products purchased in the Canada are covered only in the Canada. Products purchased in the U.S.A. are covered only in the U.S.A.

● LENGTH OF WARRANTY:

This Warranty is in effect for one year from the date of the first consumer purchase.

● WHO IS COVERED:

This Warranty only covers the original purchaser of the product, who must reside in the United States, Puerto Rico or Canada.

● WHAT IS COVERED:

This Warranty covers defects in materials or workmanship (parts and labor) in the product.

● WHAT IS NOT COVERED:

This Warranty does not cover the following:

① Damage occurring during shipment of the product to Alpine for repair (claims must be presented to the carrier).
② Damage caused by accident or abuse, including burned voice coils caused by over-driving the speaker (amplifier level is turned up and driven into distortion or clipping). Speaker mechanical failure (e.g. punctures, tears or rips). Cracked or damaged LCD panels. Dropped or damaged hard drives.
③ Damage caused by negligence, misuse, improper operation or failure to follow instructions contained in the Owner’s manual.
④ Damage caused by act of God, including without limitation, earthquake, fire, flood, storms or other acts of nature. Any cost or expense related to the removal or reinstallation of the product.
⑤ Service performed by an unauthorized person, company or association.
⑥ Any product which has the serial number defaced, altered or removed.
⑦ Any product which has been adjusted, altered or modified without Alpine’s consent.
⑧ Any product not distributed by Alpine within the United States, Puerto Rico or Canada.
⑨ Any product not purchased from an Authorized Alpine Dealer.

● HOW TO OBTAIN WARRANTY SERVICE:

① You are responsible for delivery of the product to an Authorized Alpine Service Center or Alpine for repair and for payment of any initial shipping charges. Alpine will, at its option, repair or replace the product with a new or reconditioned product without charge. If the repairs are covered by the warranty, and if the product was shipped to an Authorized Alpine Service Center or Alpine, Alpine will pay the return shipping charges.
② You should provide a detailed description of the problem(s) for which service is required.
③ You must supply proof of your purchase of the product.
④ You must package the product securely to avoid damage during shipment. To prevent lost packages it is recommended to use a carrier that provides a tracking service.

● HOW WE LIMIT IMPLIED WARRANTIES:

ANY IMPLIED WARRANTIES INCLUDING FITNESS FOR USE AND MERCHANTABILITY ARE LIMITED IN DURATION TO THE PERIOD OF THE EXPRESS WARRANTY SET FORTH ABOVE AND NO PERSON IS AUTHORIZED TO ASSUME FOR ALPINE ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OF THE PRODUCT.

● HOW WE EXCLUDE CERTAIN DAMAGES:

ALPINE EXPRESSLY DISCLAIMS LIABILITY FOR INCIDENTAL AND CONSEQUENTIAL DAMAGES CAUSED BY THE PRODUCT. THE TERM “INCIDENTAL DAMAGES” REFERS TO EXPENSES OF TRANSPORTING THE PRODUCT TO THE ALPINE SERVICE CENTER, LOSS OF THE ORIGINAL PURCHASER’S TIME, LOSS OF THE USE OF THE PRODUCT, BUS FARES, CAR RENTALS OR OTHERS COSTS RELATING TO THE CARE AND CUSTODY OF THE PRODUCT. THE TERM “CONSEQUENTIAL DAMAGES” REFERS TO THE COST OF REPAIRING OR REPLACING OTHER PROPERTY WHICH IS DAMAGED WHEN THIS PRODUCT DOES NOT WORK PROPERLY. THE REMEDIES PROVIDED UNDER THIS WARRANTY ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS.

● HOW STATE/PROVINCIAL LAW RELATES TO THE WARRANTY:

This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state and province to province. In addition, some states/provinces do not allow limitations on how long an implied warranty lasts, and some do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, limitations as to these matters contained herein may not apply to you.

● IN CANADA ONLY:

This Warranty is not valid unless your Alpine car audio product has been installed in your vehicle by an Authorized Installation Center, and this warranty stamped upon installation by the installation center.

● HOW TO CONTACT CUSTOMER SERVICE:

Should the product require service, please call the following number for your nearest Authorized Alpine Service Center.

CAR AUDIO	**1-800-ALPINE-1 (1-800-257-4631)**
NAVIGATION	**1-888-NAV-HELP (1-888-628-4357)**

Or visit our website at; http://www.alpine-usa.com

ALPINE ELECTRONICS OF AMERICA, INC., 19145 Gramercy Place, Torrance, California 90501, U.S.A.
ALPINE ELECTRONICS OF CANADA, INC., 777 Supertest Road, Toronto, Ontario M3J 2M9, Canada
Do not send products to these addresses.
Call the toll free telephone number or visit the website to locate a service center.

About the Rules of Bluetooth Electromagnetic Radiation Regulation

<table>
<tr><td>USA/Canada</td><td>This device complies with Part 15 of the FCC Rules and RSS-Gen of IC Rules. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.
FCC WARNING
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</td></tr>
<tr><td>Brasil</td><td>Resolução 506 – ANATEL:
“Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário.”
Para consultas, visite: www.anatel.gov.br
Resolução 242/2000:
Este equipamento está homologado pela ANATEL de acordo com os procedimentos regulamentados pela Resolução 242/2000 e atende aos requisitos técnicos aplicados.</td></tr>
<tr><td>México</td><td>Este equipo opera a titulo secundario, consecuentemente, debe aceptar interferencias perjudiciales incluyendo equipos de la misma clase y puede no causar interferencias a sistemas operando a titulo primario.
Información de producto
Modelo — CDE-126BT
Descripción — MP3/WMA/AAC CD RADIO CON BLUETOOTH®
Importador — Ampliaudio S.A. de C.V.
Domicilio de Importador — Av, Urbina No. 14, Colonia Industrial Mexico City, MEXICO 53370
Telefono de Importador — (52155) 5107-0447
País de origen — Hecho en China Fabricado en China
Fuente de alimentación — 12V C.C. Negativo a chasis
Información de producto
Modelo — CDE-125BT
Descripción — MP3 CD RADIO CON BLUETOOTH®
Importador — Ampliaudio S.A. de C.V.
Domicilio de Importador — Av, Urbina No. 14, Colonia Industrial Mexico City, MEXICO 53370
Telefono de Importador — (52155) 5107-0447
País de origen — Hecho en China Fabricado en China
Fuente de alimentación — 12V C.C. Negativo a chasis</td></tr>
</table>

ALPINE®

MP3/WMA/AAC CD RECEIVER WITH BLUETOOTH®

CDE-126BT

MP3 CD RECEIVER WITH BLUETOOTH®

CDE-125BT





(CDE-126BT only)

QUICK REFERENCE GUIDE
GUIDE DE RÉFÉRENCE RAPIDE
GUÍA DE REFERENCIA RÁPIDA

For details on all functions, refer to the Owner's Manual stored in the supplied CD-ROM. (As it is data CD, the CD cannot be used for playing back music and images on the player.) If required, an ALPINE dealer will readily provide you with a print out of the Owner's Manual contained in the CD-ROM.

Pour obtenir de plus amples informations sur l'ensemble des fonctions, reportez-vous au mode d'emploi fourni sur le CD-ROM. (Étant donné qu'il s'agit d'un CD de données, ce CD ne peut pas être utilisé pour lire des fichiers audio ou image sur le lecteur.) Si vous le souhaitez, demandez à votre revendeur ALPINE de vous fournir la version papier du mode d'emploi contenu dans le CD-ROM.

Para obtener información detallada de todas las funciones, consulte el manual del propietario contenido en el CD-ROM que se suministra. (Al ser un CD de datos, el CD no se puede utilizar para reproducir música o imágenes en el reproductor.) Si es necesario, un distribuidor de ALPINE podrá facilitarle una copia impresa del manual del propietario incluido en el CD-ROM.

EN
FR
ES

ALPINE ELECTRONICS MARKETING, INC.
1-1-8 Nishi Gotanda,
Shinagawa-ku,
Tokyo 141-0031, Japan
Phone 03-5496-8231

ALPINE ELECTRONICS OF AMERICA, INC.
19145 Gramercy Place, Torrance,
California 90501, U.S.A.
Phone 1-800-ALPINE-1 (1-800-257-4631)

ALPINE ELECTRONICS OF CANADA, INC.
777 Supertest Road, Toronto,
Ontario M3J 2M9, Canada
Phone 1-800-ALPINE-1 (1-800-257-4631)

ALPINE ELECTRONICS OF AUSTRALIA PTY. LTD.
161-165 Princes Highway, Hallam
Victoria 3803, Australia
Phone 03-8787-1200

ALPINE ELECTRONICS GmbH
Wilhelm-Wagenfeld-Str. 1-3, 80807 München, Germany
Phone 089-32 42 640

ALPINE ELECTRONICS OF U.K. LTD.
Alpine House
Fletchamstead Highway, Coventry CV4 9TW, U.K.
Phone 0870-33 33 763

ALPINE ELECTRONICS FRANCE S.A.R.L.
(RCS PONTOISE B 338 101 280)
98, Rue de la Belle Etoile, Z.I. Paris Nord II,
B.P. 50016, 95945 Roissy Charles de Gaulle
Cedex, France
Phone 01-48638989

ALPINE ITALIA S.p.A.
Viale C. Colombo 8, 20090 Trezzano
Sul Naviglio (MI), Italy
Phone 02-484781

ALPINE ELECTRONICS DE ESPAÑA, S.A.
Portal de Gamarra 36, Pabellón, 32
01013 Vitoria (Alava)-APDO 133, Spain
Phone 945-283588

ALPINE ELECTRONICS (BENELUX) GmbH
Leuvensesteenweg 510-B6,
1930 Zaventem, Belgium
Phone 02-725-13 15

YAMAGATA (Wuxi) Co., Ltd.
Block 28-25,Changjiang Nanlu, WND, jiangsu, China

Designed by ALPINE Japan
Printed in China (Y)
68-16909Z36-A

Contents / Contenu / Índice

WARNING / AVERTISSEMENT / ADVERTENCIA 3

CAUTION / ATTENTION / PRUDENCIA 5

Getting Started / Mise en route / Primeros pasos 6

Radio 7

CD/MP3/WMA/AAC/USB 8

BT Hands-Free Calling / Communications mains libres BT / Llamadas manos libres con BT 10

iPod/iPhone (Optional) / iPod/iPhone (en Optional) / iPod/iPhone (opcional) 13

Setting Time / Réglage de l'heure / Ajuste de la hora 17

Specifications / Spécifications / Especificaciones 19

Installation / Installation / Instalación 21

Connections / Raccordements / Conexiones 23

IMPORTANT

Please record the serial number of your unit in the space provided below and keep it as a permanent record.

SERIAL NUMBER: _____

INSTALLATION DATE: _____

INSTALLATION TECHNICIAN: _____

PLACE OF PURCHASE: _____

IMPORTANT

Veuillez inscrire le numéro de série de votre appareil dans l'espace prévu ci-contre et conservez-le soigneusement dans vos archives.

NUMÉRO DE SÉRIE : _____

DATE D'INSTALLATION : _____

INSTALLATEUR : _____

LIEU D'ACHAT : _____

IMPORTANTE

Anote el número de serie de la unidad en el espacio proporcionado a continuación y consérvelo como registro permanente.

NÚMERO DE SERIE: _____

FECHA DE INSTALACIÓN: _____

INSTALADOR: _____

LUGAR DE ADQUISICIÓN: _____

⚠WARNING

This symbol means important instructions. Failure to heed them can result in serious injury or death.

DO NOT OPERATE ANY FUNCTION THAT TAKES YOUR ATTENTION AWAY FROM SAFELY DRIVING YOUR VEHICLE.
Any function that requires your prolonged attention should only be performed after coming to a complete stop. Always stop the vehicle in a safe location before performing these functions. Failure to do so may result in an accident.

KEEP THE VOLUME AT A LEVEL WHERE YOU CAN STILL HEAR OUTSIDE NOISES WHILE DRIVING.
Excessive volume levels that obscure sounds such as emergency vehicle sirens or road warning signals (train crossings, etc.) can be dangerous and may result in an accident. LISTENING AT LOUD VOLUME LEVELS IN A CAR MAY ALSO CAUSE HEARING DAMAGE.

MINIMIZE DISPLAY VIEWING WHILE DRIVING.
Viewing the display may distract the driver from looking ahead of the vehicle and cause an accident.

DO NOT DISASSEMBLE OR ALTER.
Doing so may result in an accident, fire or electric shock.

USE ONLY IN CARS WITH A 12 VOLT NEGATIVE GROUND.
(Check with your dealer if you are not sure.) Failure to do so may result in fire, etc.

KEEP SMALL OBJECTS SUCH AS BATTERIES OUT OF THE REACH OF CHILDREN.
Swallowing them may result in serious injury. If swallowed, consult a physician immediately.

USE THE CORRECT AMPERE RATING WHEN REPLACING FUSES.
Failure to do so may result in fire or electric shock.

DO NOT BLOCK VENTS OR RADIATOR PANELS.
Doing so may cause heat to build up inside and may result in fire.

⚠AVERTISSEMENT

Ce symbole désigne des instructions importantes. Le non-respect de ces instructions peut entraîner de graves blessures, voire la mort.

N'ACTIVER AUCUNE FONCTION SUSCEPTIBLE DE DETOURNER VOTRE ATTENTION DE LA CONDUITE DU VEHICULE.
Les fonctions requérant une attention prolongée ne doivent être exploitées qu'à l'arrêt complet du véhicule. Toujours arrêter le véhicule à un endroit sûr avant d'activer ces fonctions. Il y a risque de provoquer un accident.

GARDER LE VOLUME À FAIBLE NIVEAU DE MANIÈRE À POUVOIR ENTENDRE LES BRUITS EXTÉRIEURS PENDANT LA CONDUITE.
Des niveaux de volume excessifs qui couvrent les sirènes des ambulances ou les signaux routiers (passages à niveau, etc.) peuvent être dangereux et provoquer un accident. UN NIVEAU DE VOLUME TROP ÉLEVÉ À L'INTÉRIEUR DU VÉHICULE PEUT ÉGALEMENT AVOIR DES EFFETS IRRÉVERSIBLES SUR VOTRE AUDITION.

MINIMISER L'AFFICHAGE EN COURS DE CONDUITE.
La visualisation de l'affichage peut distraire le conducteur de la conduite du véhicule et, partant, de provoquer un accident.

NE PAS DESASSEMBLER NI MODIFIER L'APPAREIL.
Il y a risque d'accident, d'incendie ou de choc électrique.

A UTILISER UNIQUEMENT SUR DES VOITURES A MASSE NEGATIVE DE 12 VOLTS.
(Vérifiez auprès de votre concessionnaire si vous n'en êtes pas certain.) Il y a risque d'incendie, etc.

GARDER LES PETITS OBJETS COMME LES PILES HORS DE PORTEE DES ENFANTS.
L'ingestion de tels objets peut entraîner de graves blessures. En cas d'ingestion, consulter immédiatement un médecin.

UTILISER DES FUSIBLES DE L'AMPERAGE APPROPRIE.
Il y a risque d'incendie ou de décharge électrique.

NE PAS OBSTRUER LES SORTIES D'AIR NI LES PANNEAUX DU RADIATEUR.
Une surchauffe interne peut se produire et provoquer un incendie.

⚠ADVERTENCIA

Este símbolo indica que las instrucciones son importantes. De no tenerse en cuenta, podría ocasionarse heridas graves o muerte.

NO REALICE NINGUNA OPERACIÓN QUE PUEDA DISTRAER SU ATENCIÓN Y COMPROMETER LA SEGURIDAD DURANTE LA CONDUCCIÓN DEL VEHÍCULO.
Las operaciones que requieren su atención durante más tiempo sólo deben realizarse después de detener completamente el vehículo. Estacione el vehículo en un lugar seguro antes de realizar dichas operaciones. De lo contrario, podría ocasionar un accidente.

MANTENGA EL VOLUMEN A UN NIVEL QUE NO LE IMPIDA ESCUCHAR LOS SONIDOS DEL EXTERIOR MIENTRAS CONDUCE.
Los niveles de volumen demasiado altos que reducen la percepción de otros sonidos como las sirenas de emergencia o posibles señales acústicas de advertencia en carretera (cruces de trenes, etc.) podrían ser peligrosos y provocar un accidente. LOS NIVELES DE VOLUMEN ALTOS EN EL VEHÍCULO TAMBIÉN PUEDEN DAÑAR EL SISTEMA AUDITIVO DE LOS PASAJEROS.

REDUZCA AL MÁXIMO LA VISUALIZACIÓN DE LA PANTALLA MIENTRAS CONDUCE.
El conductor puede distraer su atención de la carretera mientras mira la pantalla y ocasionar un accidente.

NO DESMONTE NI ALTERE LA UNIDAD.
Si lo hace, podrá ocasionar un accidente, un incendio o una descarga eléctrica.

UTILICE LA UNIDAD SOLAMENTE EN VEHÍCULOS QUE TENGAN 12 VOLTIOS CON NEGATIVO A MASA.
(Consulte a su distribuidor en caso de duda.) De no ser así, podría ocasionar un incendio, etc.

MANTENGA LOS OBJETOS PEQUEÑOS, COMO LAS PILAS, FUERA DEL ALCANCE DE LOS NIÑOS.
La ingestión de estos objetos puede provocar lesiones graves. Si esto ocurre, consulte con un médico inmediatamente.

UTILICE EL AMPERAJE CORRECTO CUANDO CAMBIE FUSIBLES.
De lo contrario, puede producirse un incendio o una descarga eléctrica.

NO OBSTRUYA LOS ORIFICIOS DE VENTILACIÓN O LOS PANELES DEL RADIADOR.
Si los bloquea, el calor podría acumularse en el interior y producir un incendio.

USE THIS PRODUCT FOR MOBILE 12V APPLICATIONS.
Use for other than its designed application may result in fire, electric shock or other injury.

DO NOT PLACE HANDS, FINGERS OR FOREIGN OBJECTS IN INSERTION SLOTS OR GAPS.
Doing so may result in personal injury or damage to the product.

MAKE THE CORRECT CONNECTIONS.
Failure to make the proper connections may result in fire or product damage.

BEFORE WIRING, DISCONNECT THE CABLE FROM THE NEGATIVE BATTERY TERMINAL.
Failure to do so may result in electric shock or injury due to electrical shorts.

DO NOT ALLOW CABLES TO BECOME ENTANGLED IN SURROUNDING OBJECTS.
Arrange wiring and cables in compliance with the manual to prevent obstructions when driving. Cables or wiring that obstruct or hang up on places such as the steering wheel, gear lever, brake pedals, etc. can be extremely hazardous.

DO NOT SPLICE INTO ELECTRICAL CABLES.
Never cut away cable insulation to supply power to other equipment. Doing so will exceed the current carrying capacity of the wire and result in fire or electric shock.

DO NOT DAMAGE PIPE OR WIRING WHEN DRILLING HOLES.
When drilling holes in the chassis for installation, take precautions so as not to contact, damage or obstruct pipes, fuel lines, tanks or electrical wiring. Failure to take such precautions may result in fire.

DO NOT USE BOLTS OR NUTS IN THE BRAKE OR STEERING SYSTEMS TO MAKE GROUND CONNECTIONS.
Bolts or nuts used for the brake or steering systems (or any other safety-related system), or tanks should NEVER be used for installations or ground connections. Using such parts could disable control of the vehicle and cause fire etc.

DO NOT INSTALL IN LOCATIONS WHICH MIGHT HINDER VEHICLE OPERATION, SUCH AS THE STEERING WHEEL OR GEARSHIFT.
Doing so may obstruct forward vision or hamper movement etc. and results in serious accident.

UTILISER CET APPAREIL POUR DES APPLICATIONS MOBILES DE 12 V.
Toute utilisation autre que l'application désignée comporte un risque d'incendie, de choc électrique ou de blessure.

NE PAS INTRODUIRE LES MAINS, LES DOIGTS NI DE CORPS ETRANGERS DANS LES FENTES ET LES INTERSTICES.
Il y a risque de blessures ou de dommages à l'appareil.

EFFECTUER CORRECTEMENT LES CONNEXIONS.
Il y a risque de blessures ou de dommages à l'appareil.

AVANT TOUTE CONNEXION, DEBRANCHER LE CABLE DE LA BORNE NEGATIVE DE LA BATTERIE.
Il y a risque de choc électrique ou de blessure par courts-circuits.

NE PAS COINCER LES CABLES AVEC DES OBJETS VOISINS.
Positionner les câbles conformément au manuel de manière à éviter toute obstruction en cours de conduite. Les câbles qui obstruent ou dépassent à des endroits tels que le volant, le levier de changement de vitesses, la pédale de frein, etc., peuvent s'avérer extrêmement dangereux.

NE PAS DENUDER LES CABLES ELECTRIQUES.
Ne jamais enlever la gaine isolante pour alimenter un autre appareil. Il y a risque de dépassement de la capacité de courant et, partant, d'incendie ou de choc électrique.

NE PAS ENDOMMAGER DE CONDUITES NI DE CABLES LORS DU FORAGE DES TROUS.
Lors du forage de trous dans le châssis en vue de l'installation, veiller à ne pas entrer en contact, endommager ni obstruer de conduites, de tuyaux à carburant ou de fils électriques. Le non-respect de cette précaution peut entraîner un incendie.

NE PAS UTILISER DES ECROUS NI DES BOULONS DU CIRCUIT DE FREINAGE OU DE DIRECTION POUR LES CONNEXIONS DE MASSE.
Les boulons et les écrous utilisés pour les circuits de freinage et de direction (ou de tout autre système de sécurité) ou les réservoirs ne peuvent JAMAIS être utilisés pour l'installation ou la liaison à la masse. L'utilisation de ces organes peut désactiver le système de contrôle du véhicule et causer un incendie, etc.

NE PAS INSTALLER A DES ENDROITS SUSCEPTIBLES D'ENTRAVER LA CONDUITE DU VEHICULE, COMME LE VOLANT OU LE LEVIER DE VITESSES.
La vue vers l'avant pourrait être obstruée ou les mouvements gênés, etc., et provoquer un accident grave.

UTILICE ESTE PRODUCTO CON APLICACIONES MÓVILES DE 12 V.
Si se emplea para otra aplicación distinta de la prevista, podría producirse un incendio, una descarga eléctrica u otras lesiones.

NO INTRODUZCA LAS MANOS, LOS DEDOS NI OTROS OBJETOS EXTRAÑOS EN LAS RANURAS DE INSERCIÓN O EN LAS ABERTURAS.
Si lo hiciera, podría sufrir heridas u ocasionar daños al equipo.

REALICE LAS CONEXIONES CORRECTAMENTE.
Una conexión incorrecta puede producir un incendio o dañar el equipo.

ANTES DE EFECTUAR EL CABLEADO, DESCONECTE EL CABLE DEL TERMINAL NEGATIVO DE LA BATERÍA.
De no hacerlo así, podría ocasionar una descarga eléctrica o heridas debido a cortocircuitos eléctricos.

IMPIDA QUE LOS CABLES SE ENREDEN CON LOS OBJETOS SITUADOS ALREDEDOR.
Disponga la instalación eléctrica y los cables conforme a lo descrito en el manual para evitar obstáculos durante la conducción. Los cables que obstaculizan la conducción o que cuelgan de partes del vehículo como el volante de dirección, la palanca de cambios, los pedales de freno, etc., se consideran extremadamente peligrosos.

NO EMPALME CABLES ELÉCTRICOS.
Nunca corte el aislamiento de un cable para suministrar energía a otro equipo. Esto hace que la capacidad portadora del cable se supere y puede ser la causa de incendios o descargas eléctricas.

EVITE DAÑAR LOS TUBOS Y EL CABLEADO CUANDO TALADRE AGUJEROS.
Si taladra agujeros en el chasis durante la instalación, tome las precauciones necesarias para no rozar, dañar u obstruir los tubos, las tuberías de combustible, los depósitos o el cableado eléctrico. De lo contrario, podría provocar un incendio.

NO UTILICE TUERCAS O PERNOS EN EL SISTEMA DE FRENOS O DE DIRECCIÓN PARA REALIZAR LAS CONEXIONES A MASA.
Los pernos o tuercas empleados en los sistemas de freno o de dirección (o en cualquier otro sistema relacionado con la seguridad del vehículo), o los depósitos, NUNCA deben utilizarse para instalaciones de cableado o conexión a masa. Si utiliza tales partes podrá incapacitar el control del vehículo y provocar un incendio, etc.

NO INSTALE EL EQUIPO EN LUGARES QUE PUEDAN INTERFERIR CON LA OPERACIÓN DEL VEHÍCULO, COMO EL VOLANTE DE DIRECCIÓN O LA CAJA DE CAMBIOS DE VELOCIDAD.
Esto podría obstaculizar la visibilidad y dificultar el movimiento, etc. y provocar accidentes graves.

⚠CAUTION

This symbol means important instructions. Failure to heed them can result in injury or material property damage.

HALT USE IMMEDIATELY IF A PROBLEM APPEARS.

Failure to do so may cause personal injury or damage to the product. Return it to your authorized Alpine dealer or the nearest Alpine Service Center for repairing.

HAVE THE WIRING AND INSTALLATION DONE BY EXPERTS.

The wiring and installation of this unit requires special technical skill and experience. To ensure safety, always contact the dealer where you purchased this product to have the work done.

USE SPECIFIED ACCESSORY PARTS AND INSTALL THEM SECURELY.

Be sure to use only the specified accessory parts. Use of other than designated parts may damage this unit internally or may not securely install the unit in place. This may cause parts to become loose resulting in hazards or product failure.

ARRANGE THE WIRING SO IT IS NOT CRIMPED OR PINCHED BY A SHARP METAL EDGE.

Route the cables and wiring away from moving parts (like the seat rails) or sharp or pointed edges. This will prevent crimping and damage to the wiring. If wiring passes through a hole in metal, use a rubber grommet to prevent the wire's insulation from being cut by the metal edge of the hole.

DO NOT INSTALL IN LOCATIONS WITH HIGH MOISTURE OR DUST.

Avoid installing the unit in locations with high incidence of moisture or dust. Moisture or dust that penetrates into this unit may result in product failure.

⚠ATTENTION

Ce symbole désigne des instructions importantes. Le non-respect de ces instructions peut entraîner des blessures ou des dégâts matériels.

INTERROMPRE TOUTE UTILISATION EN CAS DE PROBLEME.

Le non-respect de cette précaution peut entraîner des blessures ou endommager l'appareil. Retourner l'appareil auprès du distributeur Alpine agréé ou un centre de service après-vente Alpine en vue de la réparation.

FAIRE INSTALLER LE CABLAGE ET L'APPAREIL PAR DES EXPERTS.

Le câblage et l'installation de cet appareil requiert des compétences techniques et de l'expérience. Pour garantir la sécurité, faire procéder à l'installation de cet appareil par le distributeur qui vous l'a vendu.

UTILISER LES ACCESSOIRES SPECIFIES ET LES INSTALLER CORRECTEMENT.

Utiliser uniquement les accessoires spécifiés. L'utilisation d'autres composants que les composants spécifiés peut causer des dommages internes à cet appareil ou son installation risque de ne pas être effectuée correctement. Les pièces utilisées risquent de se desserrer et de provoquer des dommages ou une défaillance de l'appareil.

FAIRE CHEMINER LE CABLAGE DE MANIERE A NE PAS LE COINCER CONTRE UNE ARETE METALLIQUE.

Faire cheminer les câbles à l'écart des pièces mobiles (comme les rails d'un siège) et des arêtes acérées ou pointues. Cela évitera ainsi de coincer et d'endommager les câbles. Si un câble passe dans un orifice métallique, utiliser un passe-cloison en caoutchouc pour éviter que la gaine isolante du câble ne soit endommagée par le rebord métallique de l'orifice.

NE PAS INSTALLER A DES ENDROITS TRES HUMIDES OU POUSSIEREUX.

Eviter d'installer l'appareil à des endroits soumis à une forte humidité ou à de la poussière en excès. La pénétration d'humidité ou de poussière à l'intérieur de cet appareil risque de provoquer une défaillance.

⚠PRUDENCIA

Este símbolo indica que las instrucciones son importantes. De no tenerse en cuenta, podría ocasionarse heridas graves o daños materiales.

DEJE DE USAR LA UNIDAD INMEDIATAMENTE SI APARECE ALGÚN PROBLEMA.

Su uso en estas condiciones podría ocasionar lesiones personales o daños al producto. Lleve la unidad a un distribuidor Alpine autorizado o al Centro de servicio Alpine más próximo para repararla.

CONFÍE EL CABLEADO Y LA INSTALACIÓN A PROFESIONALES.

El cableado y la instalación de este equipo requieren una competencia y experiencia técnica confirmada. Para garantizar la seguridad, póngase siempre en contacto con el distribuidor al que ha comprado el equipo para confiarle estas tareas.

UTILICE LOS ACCESORIOS ESPECIFICADOS E INSTÁLELOS CORRECTAMENTE.

Asegúrese de utilizar los accesorios especificados solamente. La utilización de otras piezas no designadas puede ser la causa de daños en el interior de la unidad o de una instalación incorrecta. Las piezas pueden aflojarse, lo que, además de ser peligroso, puede provocar averías.

DISPONGA EL CABLEADO DE FORMA QUE LOS CABLES NO SE DOBLEN, NO SE CONTRAIGAN NI ROCEN UN BORDE METÁLICO AFILADO.

Aleje los cables y el cableado de piezas móviles (como los raíles de los asientos) o de bordes puntiagudos o afilados. De esta forma evitará dobleces y daños en el cableado. Si los cables se introducen por un orificio de metal, utilice una arandela de goma para evitar que el borde metálico del orificio corte el aislamiento del cable.

NO INSTALE LA UNIDAD EN LUGARES MUY HÚMEDOS O LLENOS DE POLVO.

Evite instalar la unidad en lugares con altos índices de humedad o polvo. Si entra polvo o humedad, el equipo puede averiarse.

Getting Started / Mise en route / Primeros pasos



	English	*Français*	*Español*
SOURCE ⏻	**Turning Power On** Press any button (except ⏏ and ⏏) to turn power on.	**Mise sous tension** Appuyez sur une touche quelconque (à l'exception des ⏏ et ⏏) pour mettre l'appareil sous tension.	**Encendido de la unidad** Pulse cualquier botón (excepto ⏏ y ⏏) para encender la alimentación.
	Press and hold SOURCE/⏻ for at least 2 seconds to turn off the unit.	Maintenez la touche SOURCE/⏻ enfoncée pendant 2 secondes au moins pour mettre l'appareil hors tension.	Mantenga pulsado SOURCE/⏻ durante, al menos, 2 segundos para apagar la unidad.
SOURCE ⏻	**Changing the Source** **TUNER → DISC → USB AUDIO → iPod*[1]/AUX+*[2] → AUX → TUNER** *[1] Displayed only when the iPod/iPhone is connected and AUX+ SETUP is set to OFF.* *[2] Displayed only when the AUX+ SETUP is set to ON.*	**Changement de source** **TUNER → DISC → USB AUDIO → iPod*[1]/AUX+*[2] → AUX → TUNER** *[1] S'affiche uniquement lorsque l'iPod/iPhone est raccordé et que AUX+ SETUP est réglé sur OFF.* *[2] S'affiche uniquement lorsque AUX+ SETUP est réglé sur ON.*	**Cambio de la fuente** **TUNER → DISC → USB AUDIO → iPod*[1]/AUX+*[2] → AUX → TUNER** *[1] Sólo se muestra si el iPod/iPhone está conectado y AUX+ SETUP está ajustado en OFF.* *[2] Se muestra sólo cuando AUX+ SETUP está ajustado en ON.*
●	**Adjusting Volume**	**Réglage du volume**	**Ajuste del volumen**
VIEW	**Displaying the Text** The display will change every time the button is pressed.	**Affichage du texte** L'affichage change chaque fois que vous appuyez sur cette touche.	**Visualización de texto** El visualizador cambiará cada vez que presione el botón.
MUTE	**MUTE ON** **MUTE OFF**	**MUTE ON** **MUTE OFF**	**MUTE ON** **MUTE OFF**

Radio



		English	*Français*	*Español*
1		**Recalling the TUNER Mode** Select the TUNER mode.	**Rappel du mode TUNER** Sélectionnez le mode TUNER.	**Invocación del modo TUNER** Seleccione el modo TUNER.
2		**Changing the Band** F1(FM1) → F2(FM2) → AM → F1(FM1)	**Changement de fréquence** F1(FM1) → F2(FM2) → AM → F1(FM1)	**Cambio de la banda** F1(FM1) → F2(FM2) → AM → F1(FM1)
3		**Presetting Stations Automatically** **Press and hold for at least 2 seconds.** The tuner will automatically seek and store 6 strong stations in the selected band.	**Préréglage automatique des stations** **Maintenez cette touche enfoncée pendant au moins 2 secondes.** Le tuner recherche et mémorise automatiquement les 6 stations les plus puissantes sur la gamme sélectionnée.	**Almacenamiento automático de emisoras** **Pulse y mantenga presionado durante, al menos, 2 segundos.** El sintonizador buscará y almacenará automáticamente 6 emisoras de señal intensa en la banda seleccionada.
4		**Tuning to Preset Stations**	**Accord d'une station préréglée**	**Sintonía de emisoras memorizadas**

CD/MP3/WMA/AAC/USB



To USB flash memory/Vers la clé USB/A la memoria flash USB

- A USB flash memory may be connected to CDE-126BT/CDE-125BT. This unit can play back files in the USB flash memory with the same controls and modes as playback of CDs containing MP3/WMA/AAC. / Une clé USB peut être connectée au CDE-126BT/CDE-125BT. La lecture des fichiers de la clé USB est effectuée à l'aide des mêmes commandes et modes que la lecture de CD contenant des fichiers MP3/WMA/AAC. / Es posible conectar una memoria flash USB a la unidad CDE-126BT/CDE-125BT. Esta unidad reproduce los archivos de la memoria flash USB con los mismos controles y modos que la reproducción de discos que contienen archivos MP3/WMA/AAC.

	English	*Français*	*Español*
TUNE/•A.ME ►/II ENT	**Pause and Playback**	**Pause et lecture**	**Pausa y reproducción**
⏮ ⏭	**Selecting the desired song** Press ⏮ or ⏭ to skip to the beginning of the current song or the next song.	**Sélection du morceau de votre choix** Appuyez sur ⏮ ou ⏭ pour passer au début du morceau en cours ou du morceau suivant.	**Selección de la canción deseada** Pulse ⏮ o ⏭ para saltar al principio de la canción actual o a la canción siguiente.
	Press and hold ⏮ or ⏭ to fast backward or fast forward.	Maintenez la touche ⏮ ou ⏭ enfoncée pour effectuer une recherche rapide vers l'arrière ou vers l'avant.	Pulse y mantenga presionado ⏮ o ⏭ para el avance o el retroceso rápido.
1◄ ►2	**Selecting the desired folder (MP3/WMA/AAC)**	**Sélection du dossier de votre choix (MP3/WMA/AAC)**	**Selección de la carpeta deseada (MP3/WMA/AAC)**

5	**M.I.X. (Random Play)** : The tracks are played back in random sequence. (CD) All files stored in the USB memory are played back in random sequence. (USB AUDIO) : Only files in a folder are played back in random sequence. (MP3/WMA/AAC) : The files are played back in random sequence. (MP3/WMA/AAC) (off) : Cancel	**M.I.X. (Lecture aléatoire)** : Les pistes sont lues dans un ordre aléatoire. (CD) Tous les fichiers enregistrés dans la clé USB sont lus dans un ordre aléatoire. (USB AUDIO) : Seuls les fichiers d'un dossier sont lus dans un ordre aléatoire. (MP3/WMA/AAC) : Les fichiers sont lus dans un ordre aléatoire. (MP3/WMA/AAC) (off) : Annulation	**M.I.X. (Reproducción aleatoria)** : Las pistas se reproducen en secuencia aleatoria. (CD) Todos los archivos guardados en la memoria USB se reproducen en orden aleatorio. (USB AUDIO) : Sólo se reproducen en secuencia aleatoria los archivos incluidos en una carpeta. (MP3/WMA/AAC) : Los archivos se reproducen en secuencia aleatoria. (MP3/WMA/AAC) (off) : Cancelar
4	**Repeat Play** : Only a track is repeatedly played back. : Only files in a folder are repeatedly played back. (MP3/WMA/AAC) (off) : Cancel	**Lecture répétée** : Une seule piste est lue d'une manière répétée. : Seuls les fichiers d'un dossier sont lus d'une manière répétée. (MP3/WMA/AAC) (off) : Annulation	**Repetición de reproducción** : Sólo se reproduce varias veces una pista. : Sólo se reproducen varias veces los archivos incluidos en una carpeta. (MP3/WMA/AAC) (off) : Cancelar
⏏	**Eject**	**Éjection**	**Expulsar**

BT Hands-Free Calling / Communications mains libres BT / Llamadas manos libres con BT



	English	*Français*	*Español*
	About BLUETOOTH BLUETOOTH is a wireless technology allowing communication between a mobile device or personal computer over short distances. This enables a hands-free call or data transmission between BLUETOOTH compatible devices. With BLUETOOTH wireless technology hands-free calls are possible when using a HSP (Head Set Profile) and HFP (Hand-Free Profile) compatible mobile phone with this unit. About how to connect the mobile phone to this unit, refer to the Owner's Manual stored in the supplied CD-ROM.	**A propos de BLUETOOTH** BLUETOOTH est une technologie sans fil qui permet à un appareil mobile et à un ordinateur de communiquer entre eux sur de courtes distances. Elle permet d'établir des communications mains libres et de transmettre des données entre des appareils compatibles BLUETOOTH. La technologie sans fil BLUETOOTH vous permet de passer et de recevoir des appels en mode mains libres en utilisant un téléphone mobile compatible HSP (Head Set Profile) et HFP (Hand-Free Profile) avec cet appareil. Pour savoir comment raccorder le téléphone portable à cette unité, reportez-vous au Mode d'emploi qui se trouve sur le CD-ROM fourni.	**Acerca de BLUETOOTH** BLUETOOTH es una tecnología inalámbrica que permite comunicarse entre un dispositivo móvil o un ordenador personal en distancias cortas. De este modo pueden realizarse llamadas manos libres o transmitir datos entre dispositivos compatibles con BLUETOOTH. Con la tecnología inalámbrica BLUETOOTH pueden realizarse llamadas manos libres si se utiliza un teléfono móvil compatible con HSP (Perfil de auriculares) y HFP (Perfil manos libres) con la unidad. En relación con la conexión del teléfono móvil a esta unidad, consulte el manual del propietario del CD-ROM suministrado.
	Answering the Incoming Call	**Réponse à l'appel entrant**	**Responder una llamada entrante**
	Hanging up the Telephone Press and hold ⌐ for at least 2 seconds to hang up the Telephone.	**Mettre fin à un appel** Appuyez sur ⌐ pendant 2 secondes au moins pour raccrocher le téléphone.	**Colgar el teléfono** Mantenga pulsada la tecla ⌐ durante por lo menos dos segundos para colgar el teléfono.

Calling / Appel / Llamadas

		English	*Français*	*Español*
1		**Activate the outgoing method list selection mode.**	**Activez le mode de sélection de la liste de la méthode sortante.**	**Active el modo de selección de llamadas salientes.**
2		**Select the desired outgoing mode.** **DIALED/RECEIVED/MISSED/ PHONE BOOK**	**Sélectionnez le mode sortant souhaité.** **DIALED/RECEIVED/MISSED/PHONE BOOK**	**Seleccione el modo de llamadas salientes que desee.** **DIALED/RECEIVED/MISSED/PHONE BOOK**
3		**Enter.**	**Accédez à la sélection.**	**Introducir.**
4		**Select the desired name or telephone number.** 	**Sélectionnez le nom ou le numéro de téléphone souhaité.** 	**Seleccione el nombre o el número de teléfono que desee.**
5		**Enter.** The selected telephone will be called.	**Accédez à la sélection.** Le téléphone sélectionné est appelé.	**Introducir.** El teléfono llamará al número seleccionado.
		Phone Book Alphabet Skip The initial skip function is skipped to the next number, symbol or letter such as from A to B, B to C. You can skip in reverse order such as B to A by pressing 1 ◄ (✓ ABC). During search mode, press 1 ◄ or ► 2 (✓ ABC) to perform the Alphabet Skip Function. A list is skipped to the next number, symbol or letter.	**Recherche alphabétique dans le répertoire téléphonique** La fonction de saut initial défile jusqu'au numéro, symbole ou lettre suivant, par exemple de A à B, de B à C. Vous pouvez faire défiler dans le sens inverse (de B à A) en appuyant sur 1 ◄ (✓ ABC). En mode de recherche, appuyez sur 1 ◄ ou ► 2 (✓ ABC) pour exécuter la fonction Recherche alphabétique. Une liste passe au numéro, symbole ou lettre suivant.	**Función de salto de inicial en la agenda** La función de salto de inicial permite pasar de un número, símbolo o letra al siguiente como, por ejemplo, de A a B, de B a C, etc. Para saltar en el orden inverso y pasar, por ejemplo, de B a A, pulse 1 ◄ (✓ ABC). En el modo de búsqueda, pulse 1 ◄ o ► 2 (✓ ABC) para utilizar la función de salto de inicial. En una lista, se pasa al siguiente número, símbolo o letra.

Voice Dial Operation / Numérotation vocale / Funcionamiento de la marcación por voz

	English	*Français*	*Español*
1	**Activate the Voice Dial mode.** Press and hold **/VOICE DIAL** for at least 2 seconds.	**Activez le mode de numérotation vocale.** Appuyez sur la touche **/VOICE DIAL** et maintenez-la enfoncée pendant au moins 2 secondes.	**Active el modo de marcación por voz.** Mantenga pulsado **/VOICE DIAL** durante, al menos, 2 segundos.
2	**Say the telephone number, name you want to call into the microphone.**	**Prononcez dans le micro le numéro de téléphone, le nom du correspondant à appeler.**	**Diga el número de teléfono o el nombre al que desea llamar por el micrófono.**
	• *You can perform this operation only when a voice dial compatible mobile phone is connected. If the mobile phone is not compatible with the voice dial, "NO SUPPORT" is displayed for 2 seconds.* • *If a called person that you say is not found, "NO CALL" is displayed for 2 seconds.* • *Voice dial operation depends on the function of the mobile phone. For details, refer to the Owner's Manual of the mobile phone.*	• *Vous ne pouvez exécuter cette opération que si vous connectez au préalable un téléphone portable compatible avec la numérotation vocale. Si le téléphone portable n'est pas compatible avec la numérotation vocale, « NO SUPPORT » s'affiche pendant 2 secondes.* • *Si le nom du correspond que vous prononcez est introuvable, « NO CALL » s'affiche pendant 2 secondes.* • *La numérotation vocale est tributaire du téléphone portable. Pour plus d'informations, reportez-vous au Mode d'emploi du téléphone portable.*	• *Solo puede realizar esta operación si hay conectado un teléfono compatible con la marcación por voz. Si el teléfono móvil no es compatible con la marcación por voz, aparecerá "NO SUPPORT" durante 2 segundos.* • *Si no se ha podido localizar a la persona a la que deseaba llamar, aparecerá "NO CALL" durante 2 segundos.* • *El funcionamiento de la marcación por voz depende de las funciones del teléfono móvil. Para obtener más información, consulte el manual del propietario del teléfono móvil.*

iPod/iPhone (Optional) / iPod/iPhone (en Optional) / iPod/iPhone (opcional)



	English	*Français*	*Español*
	An iPod/iPhone can be connected to this unit by using the proprietary ALPINE FULL SPEED Connection Cable (KCE-433iV) (Supplied, CDE-126BT only). When this unit is connected by using the cable, the controls on the iPod are not functional.	Vous pouvez raccorder un iPod/iPhone à cet appareil à l'aide du câble de raccordement propriétaire ALPINE FULL SPEED (KCE-433iV) (Fourni, CDE-126BT uniquement). Lorsque vous raccordez l'appareil à l'aide de ce câble, les commandes de l'iPod ne fonctionnent pas.	Puede conectar un iPod/iPhone a esta unidad mediante el cable de conexión exclusivo ALPINE FULL SPEED (KCE-433iV) (Suministrado, sólo CDE-126BT). Si la unidad está conectada mediante el cable, los controles del iPod no están operativos.
	Recalling the iPod Mode Select the iPod mode.	**Rappel du mode iPod** Sélectionnez le mode iPod.	**Invocación del modo iPod** Seleccione el modo iPod.
	Pause and Playback	**Pause et lecture**	**Pausa y reproducción**

Selecting the desired song

Press ⏮ or ⏭ to skip to the beginning of the current song or the next song.

Press and hold ⏮ or ⏭ to fast backward or fast forward through current song.

Sélection du morceau de votre choix

Appuyez sur ⏮ ou ⏭ pour passer au début du morceau en cours ou du morceau suivant.

Maintenez la touche ⏮ ou ⏭ enfoncée pour effectuer une recherche rapide vers l'avant/arrière au sein du morceau en cours.

Selección de la canción deseada

Pulse ⏮ o ⏭ para saltar al principio de la canción actual o a la canción siguiente.

Mantenga pulsados los botones ⏮ o ⏭ para avanzar o retroceder rápidamente en la canción actual.

5

Random Play Shuffle (M.I.X.)

(Shuffle Albums) :
Album shuffle playback plays back all songs in order, then randomly selects the next album.
(Shuffle Songs) :
Song shuffle randomly plays back songs within a selected category (playlist, album, etc.).
(off) : Cancel

Lecture aléatoire (M.I.X.)

(Lecture aléatoire des albums) :
La lecture aléatoire de l'album lit tous les morceaux dans l'ordre, puis sélectionne au hasard l'album suivant.
(Lecture aléatoire des morceaux) :
Cette fonction lit de manière aléatoire les morceaux d'une catégorie choisie (liste d'écoute, album, etc.).
(off) : Annulation

Reproducción aleatoria (M.I.X.)

(Reproducir álbumes de forma aleatoria) :
La reproducción aleatoria de álbumes reproduce todas las canciones en orden y, a continuación, selecciona el siguiente álbum de forma aleatoria.
(Reproducir canciones de forma aleatoria) :
La reproducción aleatoria de canciones reproduce las canciones de una categoría seleccionada (lista de reproducción, álbum, etc.).
(off) : Cancelar

6

Random Play Shuffle All

: Shuffle ALL plays all songs in the iPod/iPhone randomly.
(off) : Cancel

Lecture aléatoire ALL

: La lecture aléatoire ALL lit tous les morceaux de l'iPod/iPhone de manière aléatoire.
(off) : Annulation

Reproducción aleatoria Reproducir todo de forma aleatoria

: La reproducción de todo de forma aleatoria reproduce todas las canciones del iPod/iPhone de forma aleatoria.
(off) : Cancelar

4

Repeat Play

: Only a song is repeatedly played back.
(off) : Cancel

Lecture répétée

: Un seul morceau est lu d'une manière répétée.
(off) : Annulation

Repetición de reproducción

: Sólo se reproduce varias veces una canción.
(off) : Cancelar

Searching for a desired Song (iPod/iPhone) / Recherche d'un morceau souhaité (iPod/iPhone) / Búsqueda de la canción deseada (iPod/iPhone)



Hierarchy 1/Hiérarchie 1/Jerarquía 1	Hierarchy 2/Hiérarchie 2/Jerarquía 2	Hierarchy 3/Hiérarchie 3/Jerarquía 3	Hierarchy 4/Hiérarchie 4/Jerarquía 4
Playlist/Liste d'écoute/Lista de reproducción	Song/Morceau/Canción	—	—
Artist/Artiste/Artista	Album/Album/Álbum	Song/Morceau/Canción	—
Album/Album/Álbum	Song/Morceau/Canción	—	—
Song/Morceau/Canción	—	—	—
Podcast	Episode/Épisode/Episodio	—	—
Genre/Genre/Género	Artist/Artiste/Artista	Album/Album/Álbum	Song/Morceau/Canción
Composer/Compositeur/Compositor	Album/Album/Álbum	Song/Morceau/Canción	—
Audiobook/Livre audio/Audiolibro	—	—	—

		English	*Français*	*Español*
1		**Activate the search selection mode.**	**Activez le mode de sélection de recherche.**	**Active el modo de selección de búsqueda.**
2		**Select the desired search mode.** **PLAYLIST/ARTIST/ALBUM/SONG/ PODCAST/GENRE/COMPOSER/ AUDIOBOOK**	**Sélectionnez le mode de recherche de votre choix.** **PLAYLIST/ARTIST/ALBUM/SONG/ PODCAST/GENRE/COMPOSER/ AUDIOBOOK**	**Seleccione el modo de búsqueda deseado.** **PLAYLIST/ARTIST/ALBUM/SONG/ PODCAST/GENRE/COMPOSER/ AUDIOBOOK**

3	TUNE/•A.ME ►/II ENT	**Enter.**		**Accédez à la sélection.**		**Introducir.**	
4		**Select the desired title.**		**Sélectionnez le titre de votre choix.**		**Seleccione el título deseado.**	
5	TUNE/•A.ME ►/II ENT	**Enter.**	Song Search mode : The selected song is played back.	**Accédez à la sélection.**	Mode de recherche par morceau : La lecture du morceau sélectionné commence.	**Introducir.**	Modo de búsqueda de canciones : Se reproducirá la canción seleccionada.
			Others Search mode : Proceeds to the next hierarchy level. Search for a title by performing steps 4 and 5 repeatedly.		Autres modes de recherche : Passez au niveau suivant de la hiérarchie. Recherchez un titre en répétant les étapes 4 et 5.		Modo de búsqueda de otros : Permiten pasar al siguiente nivel de la jerarquía. Para buscar un título, realice los pasos 4 y 5 varias veces.
		After pressing and holding ►/II /ENT for at least 2 seconds while in each hierarchy (except SONG and AUDIOBOOK hierarchy), all songs of the selected hierarchy are played back.		*Après avoir appuyé sur ►/II /ENT pendant 2 secondes au moins au sein d'une hiérarchie (sauf les hiérarchies SONG et AUDIOBOOK), tous les morceaux de la hiérarchie sélectionnée sont lus.*		*Tras mantener pulsado ►/II /ENT por lo menos 2 segundos en cada jerarquía (excepto la jerarquía SONG y AUDIOBOOK), todas las canciones de la jerarquía seleccionada se reproducirán.*	

Setting Time / Réglage de l'heure / Ajuste de la hora



		English	*Français*	*Español*
1		**Activate the SETUP mode.** Press and hold for at least 2 seconds.	**Activez le mode SETUP.** Maintenez cette touche enfoncée pendant au moins 2 secondes.	**Active el modo SETUP.** Pulse y mantenga presionado durante, al menos, 2 segundos.
2		**Select CLOCK ADJ mode.** 	**Sélectionnez le mode CLOCK ADJ.** 	**Seleccione el modo CLOCK ADJ.**
3		**Enter.**	**Accédez à la sélection.**	**Introducir.**
4		**Adjust the hours.** 	**Réglez les heures.** 	**Ajuste la hora.**

5		**Enter.** Repeat 4 and 5 to adjust minutes.	**Accédez à la sélection.** Répétez les étapes 4 et 5 pour régler les minutes.	**Introducir.** Repita los pasos 4 y 5 para ajustar los minutos.
6		**Return to normal mode.** Press and hold for at least 2 seconds.	**Revenez au mode normal.** Maintenez cette touche enfoncée pendant au moins 2 secondes.	**Vuelva al modo normal.** Pulse y mantenga presionado durante, al menos, 2 segundos.

Specifications / Spécifications / Especificaciones

FM TUNER SECTION

Tuning Range	87.7-107.9 MHz

AM TUNER SECTION

Tuning Range	530-1,710 kHz

GENERAL

Power Requirement	14.4 V DC (11-16 V allowable)
Power Output	18 W RMS × 4*

* Primary amplifier ratings per CEA-2006 Standard

- Power output: measured at 4 Ohms and ≤ 1% THD+N
- S/N: 80 dBA (reference: 1 W into 4 Ohms)

Weight	1.5 kg (3 lbs. 4 oz)

CHASSIS SIZE

Width	178 mm (7")
Height	50 mm (2")
Depth	161 mm (6-3/8")

FM SECTION TUNER

Plage de syntonisation	87,7-107,9 MHz

AM SECTION TUNER

Plage de syntonisation	530-1 710 kHz

GÉNÉRALITÉS

Alimentation	14,4 V CC (11-16 V admissibles)
Puissance de sortie	18 W RMS × 4*

* Niveaux d'amplificateur primaire conformes à la norme CEA-2006

- Puissance de sortie : mesurée à 4 ohms et ≤ 1% THD+N
- Signal/bruit : 80 dBA (référence : 1 W en 4 ohms)

Poids	1,5 kg (3 lbs. 4 oz)

DIMENSIONS DU CHÂSSIS

Largeur	178 mm (7")
Hauteur	50 mm (2")
Profondeur	161 mm (6-3/8")

FM TUNER SECCIÓN

Rango de sintonía	87,7-107,9 MHz

AM TUNER SECCIÓN

Rango de sintonía	530-1.710 kHz

GENERAL

Alimentación	14,4 V CC (11-16 V margen permisible)
Salida de alimentación	18 W RMS × 4*

* Calificaciones del amplificador primario de acuerdo con la norma CEA-2006

- Salida de alimentación: medida a 4 ohmios y ≤ 1% THD+N
- Señal/Ruido: 80 dBA (referencia: 1 W en 4 ohmios)

Peso	1,5 kg

TAMAÑO DEL CHASIS

Anchura	178 mm
Altura	50 mm
Profundidad	161 mm

- *iPhone, iPod, iPod classic, iPod nano, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.*
- *"Made for iPod," and "Made for iPhone," mean that an electronic accessory has been designed to connect specifically to iPod, or iPhone, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.*
- *Windows Media and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.*
- *The BLUETOOTH® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Alpine Electronics, Inc. is under license.*
- *"MPEG Layer-3 audio coding technology licensed from Fraunhofer IIS and Thomson."*
- *"Supply of this product only conveys a license for private, noncommercial use and does not convey a license nor imply any right to use this product in any commercial (i.e. revenuegeneration) real time broadcasting (terrestrial, satellite, cable and/or any other media), broadcasting/ streaming via internet, intranets and/or other networks or in other electronic content distribution systems, such as pay-audio or audio-on-demand applications. An independent license for such use is required. For details, please visit http://www.mp3licensing.com"*

- *iPhone, iPod, iPod classic, iPod nano et iPod touch sont des marques déposées d'Apple Inc. enregistrées aux États-Unis et d'autres pays.*
- *"Made for iPod," et "Made for iPhone," indique que l' accessoire électronique a été spécialement conçu pour se connecter spécifiquement à un iPod, un iPhone et que les performances des standarts Apple sont garanties par les concepteurs. Apple n'est pas responsable quand au fonctionnement de ce système ou bien du respect de celui-ci, de la législation ou des normes de sécurité en vigueur.*
- *Windows Media et le logo Windows sont des marques deposees ou des marques deposees enregistres chez Microsoft Corporation aux Etats-Unis et/ou dans d'autres pays.*
- *La marque et les logos BLUETOOTH® sont des marques de commerce appartenant à Bluetooth SIG, Inc. Ces marques sont utilisées par Alpine Electronics, Inc. sous licence.*
- *« Technologie de codage audio MPEG Layer-3 sous licence Fraunhofer IIS et Thomson. »*
- *« La fourniture de ce produit ne confère qu'une licence pour une utilisation privée de nature non commerciale, mais ne confère aucune licence et n'implique aucun droit d'utiliser ce produit pour une diffusion commerciale (c'est-à-dire générant des recettes) en temps réel (par voie terrestre, satellite, câble et/ou tout autre support), une diffusion/lecture en transit via Internet, des intranets et/ou autres réseaux ou sur tout autre système de distribution de contenu électronique tel que les applications audio à péage ou à la demande. Une licence indépendante est requise pour ce type d'utilisation. Pour plus d'informations, visitez http://www.mp3licensing.com »*

- *iPhone, iPod, iPod classic, iPod nano e iPod touch son marcas comerciales de Apple Inc., registradas en los Estados Unidos y en otros países.*
- *"Made for iPod" y "Made for iPhone" significa que un dispositivo electrónico se ha diseñado pensando específicamente en su conexión a un iPod o a un iPhone, respectivamente, y que el fabricante garantiza su conformidad con los requisitos de rendimiento de Apple. Apple no se hace responsable del funcionamiento de este dispositivo o de su cumplimiento de las normas de seguridad o legales.*
- *Windows Media y el logotipo de Windows son marcas comerciales o marcas registradas de Microsoft Corporation en los Estados Unidos y/o en otros países.*
- *La marca de la palabra BLUETOOTH® y sus logotipos son marcas comerciales registradas propiedad de Bluetooth SIG, Inc. Todo uso que Alpine Electronics, Inc. hace de dichas marcas es bajo licencia.*
- *"Tecnología de codificación de audio MPEG Layer-3 con licencia de Fraunhofer IIS y Thomson".*
- *"El suministro de este producto sólo cubre la licencia para uso privado y no comercial, y no implica una licencia ni ningún derecho de uso de este producto en ninguna difusión comercial (es decir, que genere ingresos) en tiempo real (terrestre, por satélite, por cable y/u otros medios), la difusión/reproducción mediante Internet, intranets y/u otras redes o mediante otros sistemas de distribución de contenido electrónico, como aplicaciones de audio de pago o previa petición. Es necesaria una licencia independiente para dicho uso. Si desea obtener más información, visite http://www.mp3licensing.com"*

Installation / Installation / Instalación

- *When making connections to the vehicle's electrical system, be aware of the factory installed components (e.g. on-board computer). Do not tap into these leads to provide power for this unit. When connecting the CDE-126BT/CDE-125BT to the fuse box, make sure the fuse for the intended circuit of the CDE-126BT/ CDE-125BT has the appropriate amperage. Failure to do so may result in damage to the unit and/or the vehicle. When in doubt, consult your Alpine dealer.*
- *The main unit must be mounted within 35 degrees of the horizontal plane, back to front.*



1



* *If the installed mounting sleeve is loose in the dashboard, the pressure plates may be bent slightly to remedy the problem.*

- *Lors de la connexion des câbles au système électrique du véhicule, il faut être conscient des composants installés en usine (tel qu'un ordinateur de bord). S'assurer de ne pas brancher à ces conducteurs pour fournir l'alimentation à cette unité. Lors de la connexion du CDE-126BT/ CDE-125BT au boîtier à fusible, s'assurer que le fusible du circuit désigné pour le CDE-126BT/CDE-125BT a l'ampérage approprié. Sinon, l'unité et/ou le véhicule peuvent être endommagés. En cas de doute, consulter le revendeur Alpine.*
- *L'unité principale doit être fixée à moins de 35 degrés du plan horizontal, de l'arrière vers l'avant.*



1



* *Si la gaine de montage installée n'épouse pas bien la forme du tableau de bord, les plaques de compression peuvent être légèrement plié pour remédier au problème.*

- *Cuando haga las conexiones al sistema eléctrico del vehículo, tenga en cuenta los componentes que vienen instalados de fábrica (como un computador incorporado, por ejemplo). No conecte a estos conductores para proporcionar alimentación a esta unidad. Al conectar el CDE-126BT/CDE-125BT a la caja de fusibles, asegúrese de que el fusible designado para el circuito del CDE-126BT/CDE-125BT sea del amperaje adecuado. De lo contrario, la unidad y/o el vehículo podrán sufrir daños. Cuando tenga dudas, consulte a su distribuidor Alpine.*
- *Monte la unidad principal en un ángulo de 35 grados en relación con el plano horizontal, desde atrás hacia adelante.*



1



* *Si el manguito de montaje instalado en el salpicadero está flojo, las placas de presión pueden doblarse un poco para solventar el problema.*

2



Secure the ground lead of the unit to a clean metal spot using a screw (*1) already attached to the vehicle's chassis.

- *For the screw marked "*2", use an appropriate screw for the chosen mounting location.*

3

Slide the CDE-126BT/CDE-125BT into the dashboard until it clicks. This ensures that the unit is properly locked and will not accidentally come out from the dashboard.

2



Raccordez le fil de terre de l'appareil à un point métallique propre à l'aide d'une vis (*1) déjà fixée au châssis du véhicule.

- *Pour la vis « *2 », utilisez une vis appropriée à l'emplacement de montage choisi.*

3

Glissez le CDE-126BT/CDE-125BT dans le tableau de bord jusqu'à ce qu'il émette un déclic. De cette façon, l'appareil sera convenablement fixé et il ne risquera pas de tomber accidentellement du tableau de bord.

2



Fije el cable de tierra de la unidad en un punto metálico desnudo con un tornillo (*1) ya fijado al chasis del vehículo.

- *Para el tornillo con la marca "*2", utilice un tornillo adecuado para la ubicación de montaje elegida.*

3

Deslice el CDE-126BT/CDE-125BT hacia el interior del salpicadero hasta que escuche un chasquido. Eso permite asegurarse de que la unidad queda correctamente fijada y no se salga accidentalmente del salpicadero.

Connections / Raccordements / Conexiones



GARANTIE LIMITÉE

Fidèles à leur engagement de ne fournir que des produits de qualité, ALPINE ÉLECTRONIQUE DE L'AMÉRIQUE, INC. et ALPINE ÉLECTRONIQUE DU CANADA, INC. (Alpine) sont heureuses de vous offrir cette garantie. Nous vous suggérons de le lire attentivement et en entier. Si vous avez la moindre question, veuillez contacter l'un de nos concessionnaires ou appeler directement Alpine aux numéros listés ci-dessous.

● PRODUITS COUVERTS PAR LA GARANTIE

Cette garantie couvre les produits audio de voiture et les accessoires connexes ("le produit"). Elle ne couvre les produits que dans le pays où ils ont été achetés.

● DURÉE DE LA GARANTIE

Cette garantie est en vigueur pendant un an à partir de la date du premier achat du client.

● PERSONNES PROTÉGÉES PAR LA GARANTIE

Seul l'acheteur original du produit, s'il résisde aux États-Unis, à Porto Rico ou au Canada, peut se prévaloir de la garantie.

● CE QUI EST COUVERT

Cette garantie couvre tous les défauts de matériaux et de fabrication (pièces et main d'œuvre) du produit.

● CE QUI N'EST PAS COUVERT

Cette garantie ne couvre pas ce qui suit:

① Les dommages survenus durant le transport des produits renvoyés à Alpine pour être réparés (les réclamations doivent être adressées au transporteur);

② Les dégâts provoqués par un accident ou une mauvaise utilisation, y compris des bobines acoustiques grillées suite à une surexcitation des enceintes (augmentation du niveau de l'amplificateur jusqu'à atteindre un effet de distorsion ou d'écrêtage), une défaillance mécanique des enceintes (perforations, déchirures ou fentes), panneaux LCD fissurés ou endommagés, disques durs endommagés ou ayant subi une chute.

③ Tout dégât provoqué par négligence, usage inapproprié, mauvaise utilisation ou par le non-respect des instructions indiquées dans le manuel de l'utilisateur.

④ Les dommages dus à la force majeure, notamment aux tremblements de terre, au feu, aux inondations, aux tempêtes ou aux autres cataclysmes naturels;
Les frais ou les dépenses relatifs à l'enlèvement ou à la réinstallation du produit;

⑤ Les services rendus par une personne, physique ou morale non autorisée;

⑥ Les produits dont le numéro de série a été effacé, modifié ou retiré;

⑦ Les produits qui ont été adaptés ou modifiés sans le consentement d'Alpine;

⑧ Les produits qui ne sont pas distribués par Alpine aux Etats-Unis, à Porto Rico ou au Canada;

⑨ Les produits qui n'ont pas été achetés par l'entremise d'un concessionnaire Alpine autorisé;

● COMMENT SE PRÉVALOIR DE LA GARANTIE

① Il vous faut remettre le produit nécessitant des réparations à un centre de service autorisé Alpine ou à Alpine même et en assumer les frais de transport. Alpine a le choix entre réparer le produit ou le remplacer par un produit neuf ou révisé, le tout sans frais pour vous. Si les réparations sont couvertes par la garantie et si le produit a été envoyé à un centre de service Alpine ou à Alpine, le paiement des frais de réexpédition du produit incombe Alpine.
② Vous devez donner une description détaillée des problèmes qui sont à l'origine de votre demande de réparation.
③ Vous devez joindre la preuve de votre achat du produit.
④ Vous devez emballer soigneusement le produit pour éviter tout dommage durant son transport. Pour éviter la perte de l'envoi, il est conseillé de choisir un transporteur qui propose un service de suivi des envois.

● LIMITATION DES GARANTIES TACITES

LA DURÉE DE TOUTES LES GARANTIES TACITES, Y COMPRIS LA GARANTIE D'ADAPTATION À L'UTILISATION ET LA GARANTIE DE QUALITÉ LOYALE ET MARCHANDE, EST LIMITÉE À CELLE DE LA GARANTIE EXPRESSE DÉTERMINÉE CI-DESSUS. PERSONNE N'EST AUTORISÉ À ENGAGER AUTREMENT LA RESPONSABILITÉ D'ALPINE EN VERTU DE LA VENTE D'UN PRODUIT.

● EXCLUSIONS DE LA GARANTIE

ALPINE STIPULE EXPRESSÉMENT QU'ELLE N'EST PAS RESPONSABLE DES DOMMAGES-INTÉRÊTS ET DOMMAGES INDIRECTS PROVOQUÉS PAR LE PRODUIT. LES DOMMAGES-INTÉRÊTS SONT LES FRAIS DE TRANSPORT DU PRODUIT VERS UN CENTRE DE SERVICE ALPINE, LA PERTE DE TEMPS DE L'ACHETEUR ORIGINAL, LA PERTE D'UTILISATION DU PRODUIT, LES BILLETS D'AUTOBUS, LA LOCATION DE VOITURES ET TOUS LES AUTRES FRAIS LIÉS À LA GARDE DU PRODUIT.
LES DOMMAGES INDIRECTS SONT LES FRAIS DE RÉPARATION OU DE REMPLACEMENT D'AUTRES BIENS ENDOMMAGÉS SUITE AU MAUVAIS FONCTIONNEMENT DU PRODUIT.
LES RECOURS PRÉVUS PAR LES PRÉSENTES EXCLUENT ET REMPLACENT TOUTE AUTRE FORME DE RECOURS.

● LIEN ENTRE LA GARANTIE ET LA LOI

La garantie vous donne des droits spécifiques, mais vous pouvez aussi jouir d'autres droits, qui varient d'un état ou d'une province à l'autre. En outre, certains états et certaines provinces interdisent de limiter la durée des garanties tacites ou d'exclure les dommages accessoires ou indirects. Dans ce cas, les limites et les exclusions de la garantie peuvent ne pas s'appliquer à vous.

● CLAUSE APPLICABLE AU CANADA SEULEMENT

Pour que la garantie soit valable, il faut qu'un centre d'installation autorisé ait installé le système audio pour l'auto dans votre véhicule et qu'il ait ensuite apposé son cachet sur la garantie.

● NUMÉROS D'APPEL DU SERVICE À LA CLIENTÈLE

Si vous avez besoin de nos services, veuillez appeler Alpine aux numéros ci-dessous pour le centre de service autorisé Alpine le plus proche.

AUDIO DE VOITURE	**1-800-ALPINE-1 (1-800-257-4631)**
NAVIGATION	**1-888-NAV-HELP (1-888-628-4357)**

Ou visitez notre site Web à l'adresse http://www.alpine-usa.com

ALPINE ÉLECTRONIQUE DE L'AMÉRIQUE, INC., 19145 Gramercy Place, Torrance, California 90501, U.S.A.
ALPINE ÉLECTRONIQUE DU CANADA, INC., 777 Supertest Road, Toronto, Ontario M3J 2M9, Canada
N'envoyez aucun produit à ces adresses.
Appelez notre numéro gratuit ou visitez notre site Web si vous recherchez un centre de service.

LIMITED WARRANTY

ALPINE ELECTRONICS OF AMERICA, INC. AND ALPINE OF CANADA INC. ("Alpine"), are dedicated to quality craftsmanship and are pleased to offer this Warranty. We suggest that you read it thoroughly. Should you have any questions, please contact your Dealer or contact Alpine at one of the telephone numbers listed below.

● PRODUCTS COVERED:

This Warranty covers Car Audio Products and Related Accessories ("the product"). Products purchased in the Canada are covered only in the Canada. Products purchased in the U.S.A. are covered only in the U.S.A.

● LENGTH OF WARRANTY:

This Warranty is in effect for one year from the date of the first consumer purchase.

● WHO IS COVERED:

This Warranty only covers the original purchaser of the product, who must reside in the United States, Puerto Rico or Canada.

● WHAT IS COVERED:

This Warranty covers defects in materials or workmanship (parts and labor) in the product.

● WHAT IS NOT COVERED:

This Warranty does not cover the following:

① Damage occurring during shipment of the product to Alpine for repair (claims must be presented to the carrier).
② Damage caused by accident or abuse, including burned voice coils caused by over-driving the speaker (amplifier level is turned up and driven into distortion or clipping). Speaker mechanical failure (e.g. punctures, tears or rips). Cracked or damaged LCD panels. Dropped or damaged hard drives.
③ Damage caused by negligence, misuse, improper operation or failure to follow instructions contained in the Owner's manual.
④ Damage caused by act of God, including without limitation, earthquake, fire, flood, storms or other acts of nature.
Any cost or expense related to the removal or reinstallation of the product.
⑤ Service performed by an unauthorized person, company or association.
⑥ Any product which has the serial number defaced, altered or removed.
⑦ Any product which has been adjusted, altered or modified without Alpine's consent.
⑧ Any product not distributed by Alpine within the United States, Puerto Rico or Canada.
⑨ Any product not purchased from an Authorized Alpine Dealer.

● HOW TO OBTAIN WARRANTY SERVICE:

① You are responsible for delivery of the product to an Authorized Alpine Service Center or Alpine for repair and for payment of any initial shipping charges. Alpine will, at its option, repair or replace the product with a new or reconditioned product without charge. If the repairs are covered by the warranty, and if the product was shipped to an Authorized Alpine Service Center or Alpine, Alpine will pay the return shipping charges.
② You should provide a detailed description of the problem(s) for which service is required.
③ You must supply proof of your purchase of the product.
④ You must package the product securely to avoid damage during shipment. To prevent lost packages it is recommended to use a carrier that provides a tracking service.

● HOW WE LIMIT IMPLIED WARRANTIES:

ANY IMPLIED WARRANTIES INCLUDING FITNESS FOR USE AND MERCHANTABILITY ARE LIMITED IN DURATION TO THE PERIOD OF THE EXPRESS WARRANTY SET FORTH ABOVE AND NO PERSON IS AUTHORIZED TO ASSUME FOR ALPINE ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OF THE PRODUCT.

● HOW WE EXCLUDE CERTAIN DAMAGES:

ALPINE EXPRESSLY DISCLAIMS LIABILITY FOR INCIDENTAL AND CONSEQUENTIAL DAMAGES CAUSED BY THE PRODUCT. THE TERM "INCIDENTAL DAMAGES" REFERS TO EXPENSES OF TRANSPORTING THE PRODUCT TO THE ALPINE SERVICE CENTER, LOSS OF THE ORIGINAL PURCHASER'S TIME, LOSS OF THE USE OF THE PRODUCT, BUS FARES, CAR RENTALS OR OTHERS COSTS RELATING TO THE CARE AND CUSTODY OF THE PRODUCT. THE TERM "CONSEQUENTIAL DAMAGES" REFERS TO THE COST OF REPAIRING OR REPLACING OTHER PROPERTY WHICH IS DAMAGED WHEN THIS PRODUCT DOES NOT WORK PROPERLY. THE REMEDIES PROVIDED UNDER THIS WARRANTY ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS.

● HOW STATE/PROVINCIAL LAW RELATES TO THE WARRANTY:

This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state and province to province. In addition, some states/provinces do not allow limitations on how long an implied warranty lasts, and some do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, limitations as to these matters contained herein may not apply to you.

● IN CANADA ONLY:

This Warranty is not valid unless your Alpine car audio product has been installed in your vehicle by an Authorized Installation Center, and this warranty stamped upon installation by the installation center.

● HOW TO CONTACT CUSTOMER SERVICE:

Should the product require service, please call the following number for your nearest Authorized Alpine Service Center.

CAR AUDIO	**1-800-ALPINE-1 (1-800-257-4631)**
NAVIGATION	**1-888-NAV-HELP (1-888-628-4357)**

Or visit our website at; http://www.alpine-usa.com

ALPINE ELECTRONICS OF AMERICA, INC., 19145 Gramercy Place, Torrance, California 90501, U.S.A.
ALPINE ELECTRONICS OF CANADA, INC., 777 Supertest Road, Toronto, Ontario M3J 2M9, Canada
Do not send products to these addresses.
Call the toll free telephone number or visit the website to locate a service center.

About the Rules of Bluetooth Electromagnetic Radiation Regulation

<table>
<tr><td>USA/Canada</td><td>This device complies with Part 15 of the FCC Rules and RSS-Gen of IC Rules. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.
FCC WARNING
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</td></tr>
<tr><td>Brasil</td><td>Resolução 506 – ANATEL:
"Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário."
Para consultas, visite: www.anatel.gov.br
Resolução 242/2000:
Este equipamento está homologado pela ANATEL de acordo com os procedimentos regulamentados pela Resolução 242/2000 e atende aos requisitos técnicos aplicados.</td></tr>
<tr><td>México</td><td>Este equipo opera a titulo secundario, consecuentemente, debe aceptar interferencias perjudiciales incluyendo equipos de la misma clase y puede no causar interferencias a sistemas operando a titulo primario.
Información de producto
Modelo — CDE-126BT
Descripción — MP3/WMA/AAC CD RADIO CON BLUETOOTH®
Importador — Ampliaudio S.A. de C.V.
Domicilio de Importador — Av, Urbina No. 14, Colonia Industrial Mexico City, MEXICO 53370
Telefono de Importador — (52155) 5107-0447
País de origen — Hecho en China Fabricado en China
Fuente de alimentación — 12V C.C. Negativo a chasis
Información de producto
Modelo — CDE-125BT
Descripción — MP3 CD RADIO CON BLUETOOTH®
Importador — Ampliaudio S.A. de C.V.
Domicilio de Importador — Av, Urbina No. 14, Colonia Industrial Mexico City, MEXICO 53370
Telefono de Importador — (52155) 5107-0447
País de origen — Hecho en China Fabricado en China
Fuente de alimentación — 12V C.C. Negativo a chasis</td></tr>
</table>


This is a CD-ROM containing data, and cannot be played on an audio CD player. Ceci est un CD-ROM qui contiet des donnees. Il ne peut etre joue sur un lecteur de CD-audio.
ALPINE
Mobile Media Solutions
COMPACT disc
CDE-125BT Series
CDE-126BT Series
OWNER'S MANUAL
MODE D'EMPLOI

Owner's Manual
Mode d'emploi

MADE IN CHINA

DESIGNED BY ALPINE JAPAN

FABRIQUE EN CHINE

CONCU PAR ALPINE JAPON

ALPINE ELECTRONICS, INC.

■ System Requirements

The CD can be used on the following operating systems: Microsoft®, Windows®, 95/98/Me/NT/2000/XP/VISTA/7 or Apple Mac OS X 10.4/10.5/10.6. In order to use the CD, Acrobat Reader 4.0 (or above) is required.

■ How to Use the CD

Insert the CD, open it, then click twice the file for the model purchased.

■ Caution on Handling the CD

Never try to play the CD on any other audio CD player. Resultant loud volume may cause hearing damage or damage to the speaker.

■ About Use of Software License

Concerning provided CD, you are required to use the CD in agreement/complying with the following provisions.
If you do not agree, the CD cannot be used.

■ Terms of Use

Alpine Electronics Incorporation (following Alpine) reserves all copyrights on the information provided on this CD. The contents of the CD cannot be used for copying without permission of its owners, Internet transfer, public showing, or commercial rent, lease, etc.

■ Limitation of Liability

Alpine does not guarantee correct operation of any computer component when used with the CD. Alpine also has no responsibility, direct or indirect, for damage resulting from use of this CD, and no compensation can be offered.

All products and brand names described above are trademarks or registered marks of their respective owners.

■ Configuration système

Ce CD peut être utilisé sous les systèmes d'exploitation suivants : Microsoft®, Windows®, 95/98/Me/NT/2000/XP/VISTA/7 ou Apple Mac OS X 10.4/10.5/10.6. Pour pouvoir utiliser le CD, vous devez installer Acrobat Reader 4.0 (ou ultérieur).

■ Comment utiliser le CD

Insérez le CD, ouvrez-le, puis cliquez deux fois sur le fichier du modèle que vous avez acheté.

■ Précautions lors de la manipulation du CD

N'essayez pas de lire le CD sur un autre lecteur CD.
Le cas échéant, le niveau de volume élevé pourrait endommager le haut-parleur ou provoquer des troubles auditifs.

■ À propos de l'utilisation de la licence du logiciel

Vous devez utiliser le CD fourni conformément aux conditions suivantes.
Si vous n'acceptez pas le contrat de licence, vous ne pouvez pas utiliser ce CD.

■ Conditions d'utilisation

Alpine Electronics Incorporation (Alpine) détient tous les droits d'auteur relatifs aux informations fournies dans ce CD. Le contenu de ce CD ne peut donc en aucun cas être copié, divulgué par Internet, utilisé pour une projection publique, une location commerciale ou une concession, etc., sans autorisation expresse du propriétaire.

■ Limitation de responsabilité

Alpine ne garantit pas le bon fonctionnement des composants de l'ordinateur lorsque vous utilisez ce CD. Alpine décline également toute responsabilité, directe ou indirecte, en cas de dommage lors de l'utilisation de ce CD, et n'offre aucune compensation économique.

Tous les produits et noms de marque cités ci-dessus sont des marques commerciales ou des marques déposées de leurs détenteurs respectifs.

YAMAGATA (Wuxi) Co., Ltd.
Block 28-25,Changjiang Nanlu, WND, jiangsu, China

Printed in China (Y)
68-13530Z62-A

NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES



BUSINESS REPLY MAIL
FIRST-CLASS MAIL PERMIT NO. 320 TORRANCE CA

POSTAGE WILL BE PAID BY ADDRESSEE

ATTENTION MARKETING SERVICES
ALPINE ELECTRONICS OF AMERICA INC
PO BOX 2859
TORRANCE CA 90509-9939

↑ FOR USE IN USA, PLEASE FOLD HERE AND ENSURE THAT AMERICAN ADDRESS FACES UP.

↓ FOR USE IN CANADA, PLEASE FOLD HERE AND ENSURE THAT CANADIAN ADDRESS FACES UP.

ALPINE ELECTRONICS
19145 GRAMERCY PL
TORRANCE CA 90501-9876
UNITED STATES OF AMERICA



NE PAS AFFRANCHIR
NO POSTAGE
NECESSARY
IF MAILED
TO THE
UNITED STATES



AIR MAIL
PAR AVION

BRS/CCRI No. 320

INTERNATIONAL BUSINESS REPLY MAIL/REPONSE PAYEE

PERMIT NO. 320 TORRANCE CA

POSTAGE WILL BE PAID BY ADDRESSEE

ALPINE Customer Care Registration → For easy on-line registration, go to "www.alpine-usa.com/registration"

Thank you for choosing Alpine! Register your product to protect your investment and receive up-to-date product information.

First name: _____

Last name: _____

Home address: _____
Street address

_____

_____ _____ _____
City State/Prov. Zip/Postal Code

Phone number: ( )

E-mail Address: _____

May we contact you? 1. ☐ Yes 2. ☐ No

Gender 1. ☐ Male 2. ☐ Female

Date of Birth Month: _____ Year: _____

Marital Status 1. ☐ Single 2. ☐ Married

Which ethnicity best describes yourself:

1. ☐ Caucasian
2. ☐ Hispanic
3. ☐ African-American
4. ☐ Asian
5. ☐ Other _____

Your highest level of education completed:

1. ☐ High School Student
2. ☐ High School Graduate
3. ☐ 2 Yr. Degree/Some College
4. ☐ Completed 4 Yr. College
5. ☐ Completed Graduate School

Occupation

1. ☐ Executive/Managerial
2. ☐ Secretarial/Clerical
3. ☐ Sales
4. ☐ General Labor
5. ☐ Professional
6. ☐ Engineering/Technical
7. ☐ Agriculture
8. ☐ Retired
9. ☐ Student
10. ☐ Other_____

Household Income

1. ☐ Less than $30,000
2. ☐ $30,000 - $50,000
3. ☐ $50,000 - $70,000
4. ☐ $70,000 - $90,000
5. ☐ $90,000 - $110,000
6. ☐ Over $110,000

Which of the following statements best describes you?

1. ☐ I usually have more electronic equipment than my friends
2. ☐ I am usually one of the first of my friends to buy the newest electronic equipment
3. ☐ I usually wait until a product has been out for a while before I purchase it
4. ☐ I am usually one of the first of my friends to know about the newest car
5. ☐ I usually know more about cars than my friends

Product purchased

1. ☐ Head unit
2. ☐ A/V Head unit
3. ☐ Factory Integration Technology
4. ☐ Installed Navigation
5. ☐ Amplifier
6. ☐ Speaker
7. ☐ Subwoofer
8. ☐ Multi-Channel Solution
9. ☐ Rear Seat Entertainment
10. ☐ iPod Solutions
11. ☐ Marine
12. ☐ Other_____

Model Number: _____

Serial Number: _____

Date of Purchase: Month: _____ Year: _____

If you purchased a navigation system, which A/V Head unit did you purchase?

1. ☐ Alpine → (Model No.) _____
2. ☐ Other → (Brand Name) _____

Purpose of buying this unit:

1. ☐ Addition
2. ☐ Replacement → **Previous brand replaced?**
   1. ☐ Factory installed 2. ☐ Alpine
   3. ☐ Other _____

When you purchased this Alpine unit, did you compare it with other brands?

1. ☐ Yes 2. ☐ No.

If yes, select all that apply.

1. ☐ Pioneer 2. ☐ Kenwood 3. ☐ Sony
4. ☐ JVC 5. ☐ JL 6. ☐ Rockford
7. ☐ Other:_____

Have you purchased Alpine products before?

1. ☐ Yes 2. ☐ No

Please tell us the type of vehicle you installed the Alpine component(s) into:

Make: _____ Model: _____

Model Year: _____

How was this vehicle purchased?

1. ☐ Buy 2. ☐ Lease

SEAL HERE

Thank you for your cooperation! We value your privacy. This information will remain confidential with Alpine and its affiliates.

Customer Care Registration is for Product registration.
Failure to complete and return this card does not diminish your warranty rights.

PART NO. 68-14470Z30-A